


6

Set Up and configuration



1) Touch to begin setting up the thermostat.



2) Select your language.




3) Set the clock format, time and date.



4) Touch to finalise setup.
(to setup using the App is currently unsupported)

Once setup is completed, if you need to change more settings go to the advanced menu. To access the advanced menu press for 5 seconds.




In the advanced menu the following settings can be adjusted:


Menu Item	Default	Options
LANGUAGE	English	0 = English, 1 = Français, 2 = Español 3 = Deutsch, 4 = Nederlands, 5 = Italiano
OPENTHERM	-	OpenTherm boiler data when available
CYCLE RATE	6	3, 6, 9 or 12
MINIMUM ON TIME	1 minute	1, 2, 3, 4 or 5 minutes
HEAT RANGE	Min = 5.0°C Max = 35.0°C	Min: 5°C to 21°C, Max: 21°C to 35°C
SCHEDULE OPTIONS	Daily	1 = Daily schedule, 2 = 5+2 days schedule
EXTERNAL SENSOR	No sensor	0 = No sensor, 1 = Room sensor
OPTIMISE	Opt. start OFF Opt. stop OFF	Opt. start: 0 = OFF, 1 = ON, 2 = Delayed start Opt. stop: 0 = OFF, 1 = ON
CLOCK	Format: 24h Time: --:-- Date: 01/09/16	Clock format: 1 = 12h, 2 = 24h Setup time and date
LOW LOAD CONTROL	ON	0 = OFF, 1 = ON
TEMPERATURE OFFSET	0.0°C	-1.5 °C to 1.5°C
RESET	-	Factory, schedule, WiFi and HomeKit reset
FAILSAFE	OFF	0 = OFF, 1 = ON

Wiring Diagrams


A) Wiring for basic 230V boiler




B) Wiring for Combi boiler



C) Wiring for OpenTherm boiler



D) Wiring for two-port zone valve



For other wiring diagrams visit:



<http://www.honeywelluk.com/professional-zone/resource-centre/Wiring-Diagrams/>

* See boiler specifications for correct terminals