## Active+ / freeDim Sense: Circular holder

# Helvar

### Sensor Accessory Series

- Accessory for mounting the Active+ Sense or freeDim Sense sensor to the ceiling
- Easy installation
- Suitable for flush mounting
- Sturdy structure, internal strain relief
- Available in white (3098100) or grey (3098000)



### PACKAGE CONTENTS

One set of Active+ Sense: Circular holder accessory kit consists of the following parts:

- Sensor holder
- Strain relief part
- Locking springs, 2 pieces

The circular sensor holders are packed in bags of 10 holder sets each.

# Locking pins position When starting to assembly in assembly hole (hole dim. 50-55mm)

Tolerance for dimensions  $\pm$  0,2 mm

### MATERIALS AND CONDITIONS

### **Material Specifications**

Material type	Polycarbonate
Fire retardant UV protected	Yes Yes
Colour	White, RAL 9016 as default Product code 3098100 Grey, RAL 9006 on request
	Product code 3098000

Glow-wire flammability test (GWFI) 900 °C (IEC 60695-2-12) passed at

### Operating & Storage Conditions

Ambient temperature range -20...+50 °C
Storage temperature range -40...+80 °C

Do not store in wet or humid environment!

Without any additional sealing, holder itself cannot be used to provide higher classification against ingress of dust or moisture than IP30.

### Conformity & Standards

Luminaires - Part 1: General IEC 60598-1:ed.8 2014 requirements and tests EN 60598-1:2015

Compliant with relevant EU directives, CE marked, RoHS/REACH compliant

### ASSEMBLY INSTRUCTIONS

Please refer to separate Installation guide, available on product website's Download & Links section, for instructions of how to mount the Active+/freeDim Sense sensors to the housing and the housing to the ceiling.