



—
INSTALLATION INSTRUCTION

Blank cable entry plate


OEZXP_120...380



OEZXP_120...380



OEZXP_120, OEZXP_240, OEZXP_340, OEZXP_440, OEZXP_540, OEZXP_280, OEZXP_380





Contact us

ABB Oy

P.O. Box 622
FI-65101 Vaasa
Finland

abb.com/lowvoltage