



—
INSTALLATION INSTRUCTION

Metal ring flange


OEZXX143...158R



OEZXX143...158R



OEZXX143...158R





Contact us

ABB Oy

P.O. Box 622
FI-65101 Vaasa
Finland

abb.com/lowvoltage