

# Making sure power makes its way

Consistent, safe and intelligent low-voltage power distribution and electrical installation technology

Whether industries, infrastructures or buildings: Each environment depends on a reliable power supply.

Which is why products and systems featuring maximum safety and optimum efficiency are in demand. This comprehensive portfolio for low-voltage power distribution and electrical installation technology covers every requirement — from the switchboard to the socket outlet.

# We are there when you need us

Your personal contact can be found at www.siemens.com/lowvoltage/contact

#### Catalog LV 10 · 10/2019

THE THE

You will find the latest edition and all future editions in the Siemens Industry Online Support at www.siemens.com/lowvoltage/catalogs

Refer to the Industry Mall for current prices www.siemens.com/industrymall

The products and systems listed in this catalog are developed and manufactured using a certified quality management system in accordance with DIN EN ISO 9001:2008.

#### Technical data

The technical specifications are for general information purposes only. Always heed the operating instructions and notices on individual products during assembly, operation and maintenance.

All illustrations are not binding.

© Siemens 2019

# Low-Voltage Power Distribution and Electrical Installation Technology

	Introduction	1/2
Protecting	Air Circuit Breakers	1/1
	Molded Case Circuit Breakers	2/1
	Miniature Circuit Breakers	3/1
	Residual Current Protective Devices / Arc Fault Detection Devices (AFDDs)	4/1
	Switching Devices	5/1
	Overvoltage Protection Devices	6/1
	Fuse Systems	7/1
Protecting, Switching and Isolating	Switch Disconnectors	8/1
Switching and Isolating	Transfer Switching Equipment and Load Transfer Switches	9/1
Measuring and Monitoring	Measuring Devices, Power Monitoring and Digitalization Solutions	_ 10/1
	Monitoring Devices	_ 11/1
Distribution	Transformers, Power Supply Units and Socket Outlets	_ 12/1
	Busbar Systems	_ 13/1
	Terminal Blocks	_ 14/1
	Power Distribution Boards, Motor Control Centers and Distribution Boards $\_$	15/1
	Busbar Trunking Systems	16/1
	System Cubicles, System Lighting and System Air-Conditioning	_ 17/1
	Annandiv	Λ/1

I

1

4

6

7

10

11

12

1 -4

1.0

17

1112 122



various ranges with IEC approval; other ranges are available that comply with standard IEC 60947 and standard UL 489. The system is therefore ideally suited for mechanical engineering companies and switchgear manufacturers. The full range of functionalities of molded case circuit breakers can be used for plant and equipment operating in Europe and North America, with absolute standards compliance assured.

# **Molded Case Circuit Breakers**



All the information you	need	2
Molded case circuit bre	eakers for all applications	2
Quick selection guide .		2
	Basic units and accessories	2
	3VA1 basic units up to 1000 A	2
	3VA2 basic units up to 1600 A	2/
	Trip units	2/
	Online configurator highlights	2/
3VA10-3VA25		2/:
	System overview	2/:
	Structure of the article numbers	2/:
	Internal accessories	2/:
	Manual operators	2/:
	Motor operators	2/:
	Connection technology	2/:
	Plug-in and draw-out technology	214
	Residual current devices RCD	2/!
	Communication	2/
	Locking, blocking and interlocking	2/
	Cover frame and mounting	2/0
3VA27		2/0
	System overview	2/0
	Structure of the article numbers	2/
	Accessory options	2/
	Guide frame	2/
	Electronic trip unit ETU and accessories	2/
	Accessories for connection and insulation	2/
	Motor operators and manual operators	2/
	Auxiliary release, closing coil	2/
	Interlocking	2/
3VL		2/8
	3VL up to 1600 A, IEC	. 2/8

# A multitude of additional information ...

# Information + ordering



i All the important things at a glance

## Information to get you started

For information about molded case circuit breakers, please visit our website www.siemens.com/3VA



Contact persons in your region

# We are there when you need us

You can find your local contacts at www.siemens.com/lowvoltage/contact



#### Your product in detail

The Siemens Industry Online Support portal provides comprehensive information

www.siemens.com/lowvoltage/product-support

• Technical basic information - 3VA molded case circuit breakers (109766672)

The relevant tender specifications can be found at www.siemens.com/lowvoltage/tenderspecifications

Use our conversion tool for quick and easy conversion to Siemens products

www.siemens.com/conversion-tool



#### Siemens YouTube channel

### Our video range

• 3VA molded case circuit breakers (general) bit.ly/2xNxIFA



#### Everything you need for your order

Refer to the Industry Mall for an overview of your products

• Molded case circuit breakers sie.ag/2mmLcAk

Direct forwarding to the individual products in the Industry Mall by clicking on the Article No. in the catalog or by entering this web address incl. Article No. www.siemens.com/product?Article No.



# Configurators

# Exactly the right circuit breaker for your application

The configurator reduces the time and effort required in the planning and ordering process, and allows for individual adaptations. Configure your 3VA molded case circuit

www.siemens.com/lowvoltage/3va-configurator www.siemens.com/lowvoltage/3va27-configurator

For your configured 3VA molded case circuit breaker, you can additionally find

- 3D views
- CAD data
- Unit wiring diagrams
- · Dimension drawings

# ... can be found in our online services

# **Commissioning + operation**



#### 🔅 Configuration software

## powerconfig

The combined commissioning and service tool for communication-capable measuring devices and circuit breakers from the SENTRON family.

www.siemens.com/powerconfig



#### Your product in detail

The Siemens Industry Online Support portal provides detailed technical information

www.siemens.com/lowvoltage/product-support

- Operating instructions 3VA10 3VA25, 3VA27
- Characteristic curves
- Certificates

Engineering data for CAD or CAE systems are available in the CAx Download Manager at www.siemens.com/lowvoltage/cax

### Manuals

Manuals are available for downloading in Siemens **Industry Online Support at** 

www.siemens.com/lowvoltage/manuals

- Configuration manual 3VA selectivity (109743975)
- System manual 3VA communication IEC / UL (98746267)
- Equipment manual 3VA molded case circuit breakers with IEC certificate (90318775)
- Equipment manual 3VA27 molded case circuit breakers & 3WL10 air circuit breakers (109753821)
- Communication manual 3WL10 air circuit breakers & 3VA27 molded case circuit breakers (109760220)

#### The fast track to the experts

Competent expert advice on technical questions with a wide range of demand-optimized services for all our products and systems.

Assistance with technical queries is provided at www.siemens.com/lowvoltage/support-request

We offer a comprehensive portfolio of services. You can find your local contacts at www.siemens.com/lowvoltage/contact

You can find further information on services at www.siemens.com/service-catalog



#### **Training and tutorials**

Our training courses can be found at www.siemens.com/sitrain-lowvoltage

- Protection systems in low-voltage power distribution (WT-LVAPS)
- Communication with SENTRON components (LV-COM)



#### Technical overview of molded case circuit breakers



#### The fast way to get you to our online services

This page provides you with comprehensive information and links on molded case circuit breakers www.siemens.com/lowvoltage/product-support (109767421)

# Molded case circuit breakers for all applications



3VA10 ... 3VA15 molded case circuit breakers

# Setting standards for standard applications

The 3VA1 molded case circuit breaker is ideally suited for your standard applications in infrastructure and industrial facilities. It is equipped with a thermal-magnetic trip unit, and offers reliable protection for plants and generators.

With its compact dimensions and depth of just 70 mm, the 3VA1 molded case circuit breaker can even fit into locations where space is limited. Thanks to its cover size of 45 mm, it is also ideally suited for use in distribution boards up to 250 A.

#### **Special features**

- Compact design
- AC/DC applications
- No derating up to +50 °C
- Optimized for distribution boards (45 mm cover size)
- Universal platform of accessories
- 1, 2, 3 or 4-pole versions



3VA20 ... 3VA25 molded case circuit breakers

# The power to deliver in demanding applications

If you are looking for a solution that lets you handle your most technically demanding projects in industrial and infrastructure applications with ease, the 3VA2 molded case circuit breaker has the special capabilities you need. It combines high breaking capacity, a range of electronic trip units (ETUs), very good selectivity properties, and various additional functionalities.

#### **Special features**

- Very good selective protection response
- AC applications
- No derating up to +50 °C
- Integrated metering function
- Connection to a communication system
- Performance range from 25 ... 1000 A



3VA27 molded case circuit breaker

Depending on the application, the 3VA27 molded case circuit breaker handles line/motor and starter protection for low-voltage electrical power distribution, and supplements the existing IEC portfolio with a rated current of 1600 A.

#### **Special features**

- Choice between two ranges of electronic trip units with a number of equipment versions
- Variable and versatile connections
- Connection to a communication system
- Can be used as a platform circuit breaker with the 3WL10 ACB, with an extensive range of common accessories
- Performance range from 800 ... 1600 A

# Basic units and accessories













Protective functions	3VA10	3VA11	3VA12	3VA13	3VA14	3VA15 new
Size	100 A	160 A	250 A	400 A	630 A	1000 A
Switch disconnectors						
No protection	-	-				-
Thermal-magnetic						
Line protection		-	-			
Starter protection	_					
Electronic						
Line protection	_	-	-	-	-	-
Line and generator protection	_	-	-	-	-	-
Line and generator protection, with display	_	-	-	-	-	-
Line and generator protection, with display, with metering function	-	-	-	-	-	-
Motor protection	-	-	-	-	-	-
Motor protection, with display	_	-	-	-	-	-
Motor protection, with display, with metering function	-	-	-	-	-	-
Starter protection	-	-	-	-	-	-

#### **Accessories**

Accessories							
Size	100 A	160 A	250 A	400 A	630 A	1000 A	
Accessories							
Auxiliary switches and signaling switches							
Auxiliary releases							
Connection technology		-	-		•		
Plug-in version	-		-	•		-	
Withdrawable	-	_	-		-	-	
Front rotary operating mechanism			-		•		
Door mounted rotary operator			-		•	•	
Side wall mounted rotary operator			-	•		-	
MO310 motor operator (mounted onto the side)	-			-	-	-	
MO320 motor operator (mounted onto the front)	-	-	-		•	-	
Motor operator with SEO520 stored energy operator	_	-	-	-	-	-	
Motor operator (MO), integrable	_	_	-	-	-	-	
Locking, blocking and interlocking			-		-		
Residual current device (mounted onto the side)	-		-	-	-	-	
Residual current device (mounted underneath)	-		-	-	-	-	
Communications interface	_	-	-	-	-	-	
EFB300	-	-	_	-	-	-	
TD300, TD400 and TD500	-	-	-	-	-	-	
Cover frame	•		-		•		
DIN rail adapter	•	-	-	-	-	-	
Busbar adapter						-	

<sup>■</sup> Available — Not available/not present

<sup>\*</sup> On request



1	00 A	160 A	250 A	400 A	630 A	1000 A	1600 A
	•		-	•			•
			-				
	•		-		•	•	
	•		-	-	•	-	-
	•		-	•		-	•
			-			•	
	•	•	-	•		•	
	•	•	-	-		-	-
	-	-	_	-	-	-	-
	•			•	•	-	-
	•	•	•	-	-	-	-
	-		_	-		-	•
	•	•	•	•	•	•	•
	-	-	-	-	-	-	-
	•	•	•	•	•	-	-
	•	•	•	•	•	•	•
	•	•	•	•		•	•
	•	-	-	•	-	•	•
	•	-	•	•	-	•	•
	-	-	-	-	-	<del>-</del>	-
		•		-		_	-

# 3VA1 basic units up to 1000 A

# Technical data

				6						1		
				3VA10	)		3VA11	1		3VA1	1	
Electrical charac	teristics according to IEC 60947-2											
Number of poles	·			3/4-pole			1-pole			2-pole		
Size				100 A			160 A			160 A		
Rated operational	current I <sub>n</sub> at 50 °C ambient temperature			6 100	A	1	6 160	Α	1	16 160	А	
Rated operational	voltage U <sub>e</sub> 50/60 Hz AC			690 V			415 V			415 V		
Rated insulation vo	oltage U <sub>i</sub>			V 008			500 V			500 V		
Rated impulse with	nstand voltage U <sub>pulse</sub>			8 kV			8 kV			8 kV		
Use in IT networks												
Frequency			(	400 Н	lz	C	400 Н	lz	(	) 400 H	łz	
Breaking capacit	ty		В	N	S	N	S	М	N	S	М	
Rated ultimate sh	ort-circuit breaking capacity I <sub>cu</sub>											
50/60 Hz AC	220 240 V	kA	25	36	55	25	36	55	36	55	85	
	380 415 V	kA	16	25	36	5	6	6	25	36	55	
	440 V	kA	8	16	25	-	-	-	-	-	-	
	500 V	kA	5	5	7	-	-	-	-	-	-	
	690 V	kA	5	5	7	-	-	-	-	_	-	
DC	125 V (1 switching pole)	kA	_	_	-	16	25	30	16	25	30	
	250 V (2 switching poles)	kA	25	36	55	-	_	-	36	55	85	
	500 V (3 switching poles)	kA	25	36	55	-	_	-	-	_	-	
	600 V (4 switching poles)	kA	8	16	25	-	_	-	_	_	_	
<b>Rated</b> operationa	l short-circuit breaking capacity I <sub>cs</sub>											
50/60 Hz AC	220 240 V	kA	25	36	55	25	35	55	36	55	85	
	380 415 V	kA	16	25	36	5	6	6	25	36	55	
	440 V	kA	8	16	25	-	-	-	-	_	-	
	500 V	kA	5	5	5	-	_	-	-	_	-	
	690 <b>V</b>	kA	5	5	5	-	-	-	_	_	-	
DC	125 V (1 switching pole)	kA	-	-	-	16	25	30	16	25	30	
	250 V (2 switching poles)	kA	25	36	55	-	-	-	36	55	85	
	500 V (3 switching poles)	kA	25	36	55	-	-	-	-	_	-	
	600 V (4 switching poles)	kA	8	16	25	-	-	-	-	_	-	
Dimensions												
- D - C - C	A	mm	76.2	(3P <b>)  </b> 101	.6 (4P)		25.4			50.8		
0115	В	mm	130			130			130			
	C	mm	70			70			70			
	D	mm		88			88			88		
■ Available – N	Not available/not present * On req	juest										











	ALC:	100			01010	<b>7</b>			100				10				
	3V	A11			3VA12	2		3V	A13			3V	414		3\	/A15 ne	ew
	3/4-	pole			3/4-pole			3/4-	pole		3/4-pole					3/4-po <b>l</b> e	
	16	0 A			250 A			40	0 A		630 A				1000 A		
	16	160 A		1	60 250	) A		320	. 400 A		500 630 A				630 1000 A		
	69	V 0			690 V			69	0 V		690 V				690 V		
	80	V 0			800 V			80	0 V			80	0 V		800 V		
	8	kV			8 kV			8	kV			8	kV			8 kV	
					-							1				Up to 500 \	/
	0 4	100 Hz	ļ.	(	400 H	-lz		0 4	100 Hz			0 4	00 Hz			0 400 Hz	1
N	S	М	H	S	M	Н	S	M	Н	С	S	M	Н	С	M	Н	С
36	55	85	100	55	85	100	55	85	100	200	55	85	100	200	85	110	200
25	36	55	70	36	55	70	36	55 *	70 *	110	36 *	55 *	70 *	110	55 *	85	110
16	25	36	55	25	36	36	*										
7	7	10	10	10	15	15	25	36	55	70	25	36	55	70	36	55	70
7	7	10	10	7	10	10	7	7	10	10	7	7	10	10	25	35	35
-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	_	-	_
36	55 55	85 85	100	55 55	85 85	100	8	16	25	25 25	8	16 16	25 25	25 25	-	-	-
36	25	36	55	25	36	100 55	8	16 16	25 25	25	8	16	25	25 25	-	-	-
16	25	36	55	25	36	55	8	16	25	25	8	16	25	25	_	-	-
36	55	85	100	55	85	100	55	85	100	200	55	85	100	200	85	110	150
25	36	55	70	36	55	70	36	55	70	110	36	55	70	110	55	85	110
16	25	36	40	25	36	36	*	*	*	*	*	*	*	*	*	*	*
5	5	5	5	10	10	10	25	36	55	70	25	36	55	70	36	55	65
5	5	5	5	5	5	5	5	5	6	6	5	5	6	6	19	19	19
_	_	_	-	_	_	_	_	_	_	_	_	_	_	-	_	_	_
36	55	85	100	55	85	100	8	16	25	25	8	16	25	25	_	_	_
36	55	85	100	55	85	100	8	16	25	25	8	16	25	25	_	_	_
16	25	36	55	25	36	55	8	16	25	25	8	16	25	25	_	_	-
7	6.2 (3P)	101.6 (4	<b>1</b> P)	105	(3P)   140	) (4P)		138 (3P)	184 (4F	?)	138 (3P)   184 (4P)				21	0 (3P)   280	(4P)
		30			158				48		248				320		
70					70				10		110				120		
88					88			1	37			1.	37		253		

# 3VA1 basic units up to 1000 A

# Application

			<b>b</b>	Í		
			3VA10	3VA11	3VA11	
Electrical characteristics	according to IEC 60947-2					
Number of poles			3/4 <b>-</b> pole	1-pole	2-pole	
Size			100 A	160 A	160 A	
Rated operational current I	<sub>n</sub> at 50 °C ambient temperature		16 100 A	16 160 A	16 160 A	
3VA1 molded case circu	it breakers for line protection, standard app	lication	s (IEC 60947-2)			
Service life (make-break o	pperations)					
Mechanical (NO contact – I	NC contact)		20000	20000	20000	
Electrical	380 415 V I <sub>n</sub>		9000	9000	9000	
	I <sub>n</sub> /2		15000	15000	15000	
	690 V		6300	6300	6300	
Trip Units						
TM210	FTFM			•		
TM220	ATFM		-	-	-	
TM240	ATAM		-	-	-	
3VA1 molded case circu	it breakers for starter protection (IEC 60947	-4-1 star	ndards and specifications	acc. to AC-1)		
·	<sub>n</sub> at 50 °C ambient temperature	Α	-	-	-	
Service life (switching cyc						
Mechanical (NO contact – I			-	-	-	
Electrical	380 415 V		-	-	-	
Trip Units						
TM120M	AM		-	-	-	
Switch disconnectors (II						
Electrical characteristics a	according to IEC 60947-3					
· · · · · · · · · · · · · · · · · · ·	t I <sub>u</sub> at 50 °C ambient temperature	Α	-	-	-	
Rated operational voltage (	C	V	-	-	-	
Rated operational voltage l	•	V	-	-	-	
	cuit current $I_{ m q}$ with upstream 3VA1 circuit breaker		-	-	-	
Permissible rated short-tim	e current I <sub>cw</sub> (1 s)	kA	-	-	-	
■ Available – Not availab	le/not present * On request					



# 3VA2 basic units up to 1600 A

# Technical data

				3V	<b>A20</b>			3V	<b>A21</b>		
Electrical charac	teristics according to IEC 60947-2										
Number of poles				3/4-	pole			3/4-	pole		
Size				10	0 A			16	0 A		
Rated operational	current I <sub>n</sub> at 50 °C ambient temperature			25	100 A			25	160 A		
Rated operational	voltage U <sub>e</sub> 50/60 Hz AC			69	0 V			69	0 V		
Rated insulation vo	oltage U <sub>i</sub>			80	V 0			80	0 V		
Rated impulse with	nstand voltage U <sub>pulse</sub>			8	kV			8	kV		
Use in IT networks				1							
Frequency				50/6	50 Hz			50/6	0 Hz		
Breaking capacit	ty		М	Н	С	L	М	Н	C	L	
Rated ultimate sh	ort-circuit breaking capacity l <sub>cu</sub>										
50/60 Hz AC	220 240 V	А	85	110	150	200	85	110	150	200	
	380 415 V	А	55	85	110	150	55	85	110	150	
	440 V	А	55	85	110	150	55	85	110	150	
	500 V	А	36	55	85	100	36	55	85	100	
	690 <b>V</b>	A	2	2	2	25	2.5	2.5	2.5	25	
DC	125 V (1 switching pole)	A	_	-	-	-	-	-	_	-	
	250 V (2 switching poles)	Α	-	-	-	-	-	-	-	-	
	500 V (3 switching poles)	Α	-	-	-	-	-	-	-	-	
	600 V (4 switching poles)	А	-	-	-	-	-	-	-	-	
Rated service sho	rt-circuit breaking capacity I <sub>cs</sub>										
50/60 Hz AC	220 240 V	А	85	110	150	200	85	110	150	200	
	380 415 V	А	55	85	110	150	55	85	110	150	
	440 V	А	55	85	110	150	55	85	110	150	
	500 V	А	36	55	85	100	36	55	85	100	
	690 V	А	2	2	2	18	2.5	2.5	2.5	18	
DC	125 V (1 switching pole)	А	_	-	-	-	-	-	-	-	
	250 V (2 switching poles)	А	-	-	-	-	-	-	-	-	
	500 V (3 switching poles)	А	-	-	-	-	-	-	-	-	
	600 V (4 switching poles)	А	-	-	-	-	-	-	_	-	
Dimensions											
. +D-	A	mm		105 (3P)	140 (4P)	)		105 (3P)	140 (4P)	)	
	В	B mm						1	31		
NSEO_01155	С	mm		3	36			3	66		
	D	mm		1	07			1	07		
		111111			٠,						












	14.7	3			. 1	1.1			1111									
	3V	<b>A22</b>			3V/	<b>A23</b>			3V/	<b>\24</b>			3VA25	5		3VA27		
		pole				pole				pole			3/4-pole		3/4-pole			
		0 A				0 A				0 A			1000 A			1600 A		
		. 250 A				400 A				630 A		63	0 1000	) A	81	00 1600	Α	
		0 V				0 V				0 V			690 V			690 V		
		0 V				0 V				0 V			800 V			1000 V		
		kV				kV				kV			8 kV			8 kV		
										0.11-			E0/60 !!-			E0/60 II-		
M		60 Hz C		М		0 Hz		M	H	0 Hz C	- 1	M	50/60 Hz H	С	M	50/60 Hz H	С	
IVI	Н	C	L	IVI	Н		L	IVI	<u> </u>	C C	L	IVI	н	L L	IVI	П	C	
85	110	150	200	85	110	150	*	85	110	150	*	85	110	200	100	150	200	
55	85	110	150	55	85	110	*	55	85	110	*	55	85	110	55	85	110	
55	85	110	150	55	85	110	*	55	85	110	*	*	*	*	55	85	100	
36	55	85	100	36	55	85	*	36	55	85	*	36	55	85	36	55	85	
3	3	3	25	5	5	5	*	6	6	6	*	25	35	35	25	36	50	
_	-	-	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	
_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	
_	_	_	_	_	_	_	_	_	_	-	_	_	_	_	_	_	-	
-	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	-	
85	110	150	200	85	110	150	*	85	110	150	*	85	110	150	100	150	200	
55	85	110	150	55	85	110	*	55	85	110	*	55	85	110	55	85	110	
55	85	110	150	55	85	110	*	55	85	110	*	*	*	*	55	85	100	
36	55	85	100	36	55	65	*	36	55	85	*	36	55	65	36	55	63	
3	3	3	18	5	5	5	*	6	6	6	*	19	19	19	25	36	36	
-	-	_	-	-	_	-	_	-	_	-	-	-	-	-	-	-	-	
_	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
_	-	_	-	-	_	_	_	_	_	-	_	_	-	-	-	_	-	
	105 (3P)	L140 (4D	۸.		138 (3P)	L 1 O 4 (4 D)			138 (3P)	104 (40)		210	(3P)   280	(AD)	210	(3P)   280	(4D)	
		140 (47 81	)			184 (4P, 48	,		138 (3P)			210	320	(47)	210	291	(41)	
		36				+0 10							120		171 (	toggle ope	rating	
	30			10		110							mechanism)   183 (stored energy operating mechanism)					
	1	07			1.	37			13	37			253			225		

# 3VA2 basic units up to 1600 A

# Application

			3VA20	3VA21
Electrical characteristics	according to IEC 60947-2			
Number of poles			3/4-pole	3/4-pole
Size			100 A	160 A
Rated operational current In	at 50 °C ambient temperature		25 100 A	25 160 A
Service life (make-break o	perations)			
Mechanical (NO contact – N	IC contact)		25000	25000
Electrical	380 415 V	I <sub>n</sub>	15000	14000
		I <sub>n</sub> /2	20000	20000
	690 V		10500	9800
Trip units				
ETU320	Ц		•	
ETU330	LIG		•	
ETU340	ELISA LI		-	
ETU350	LSI			•
ETU550/ETU850	LSI			•
ETU560/ETU860	LSIG		•	•
ETU650	LSI		-	-
ETU360	LSIG		-	-
ETU660	LSIG		-	-
3VA2 molded case circui	t breakers for motor/starte	r protection (IEC 60947-4-1	standards and specifications acc. to A	AC-1)
Rated operational current In	at 50 °C ambient temperature		-	25 100 A
Service life (make-break o	perations)			
Mechanical (NO contact – N	· · · · · · · · · · · · · · · · · · ·		-	25000
Electrical	380 415 V		-	14000
Trip units				
ETU310M	I		-	•
ETU350M	LSI		-	-
ETU550M	LSI		-	-
ETU860M	LSIG		-	•
ETU320	LJ		-	-
ETU350	LSI		-	-
ETU360	LSIG		-	-
ETU650	LSIG		<del>-</del>	-
ETU660	LSIG		-	-
■ Available — Not availabl	le/not present *	On request		



# Trip units

# Protection system for 3VA molded case circuit breakers up to 1000 A

Trip units	Thermal-magnetic	Electronic	Electronic with display	Electronic with display and metering function
	TM240  1./A  1./A  1./A  1./A  1./A  1./A	ETU350 LSI  1/A t/s l_wl t_/s l_wl Al2  1/20_18828	ETU550M LSI  A C C C C C C C C C C C C C C C C C C	ETU860M LSIG  A ESC CALL T ALZ  OK 1
	TM 2-series	ETU 3-series	ETU 5-series	ETU 8-series
Protection function	TM240 TM220 TM240	ETUDDO ETUDDO ETUDAO	ETHESO ETHESO	ETHOSO ETHOSO
Line protection	TM210, TM220, TM240	ETU320, ETU330, ETU340, ETU350	ETU550, ETU560	ETU850, ETU860
Starter protection	TM120M	ETU310M	-	-
Motor protection	-	ETU350M	ETU550M	ETU860M
Integrated functions Parameterizing	Setting and reading the parameters • In A	Setting and reading the parameters • In A and s	Setting and reading the parameters  • Via display and communication  • Fine setting of the parameters  • Reading the measured values	Setting and reading the parameters  Via display and communication  Fine setting of the parameters  Reading the measured values
Status display	-	Indicating the ETU status via LEDs	Indicating the ETU status via LEDs	Indicating the ETU status via LEDs
Interface	-	Interface for test devices	Interface for test devices	Interface for test devices
Metering function	-	-	-	Metering function integrated
Optional expansions				
24 V module	-	-	24 V module for continuous power supply (also without primary current through the molded case circuit breaker)	24 V module for continuous power supply (also without primary current through the molded case circuit breaker)
External function box	_	EFB300 external function box	EFB300 external function box for	EFB300 external function box for
Communication module	-	for connection to the ETU	COM060 communication module	connection to the ETU  COM060 communication module
Breaker data server	-	-	COM800/COM100 breaker data server with interface to PROFIBUS PROFINET Modbus RTU Ethernet (Modbus TCP)	COM800/COM100 breaker data server with interface to PROFIBUS PROFINET Modbus RTU Ethernet (Modbus TCP)
External display	-		DSP800 external display for installing in the cubicle door	DSP800 external display for installing in the cubicle door
Test device	-	TD300/TD400/TD500 test device	TD300/TD400/TD500 test device	TD300/TD400/TD500 test device

# Protection functions of the 3VA1 with thermal-magnetic trip unit

	TM120M	TM210	TM220	TM240
	AM	FTFM	ATFM	ATAM
Protections				
Starter protection		_	-	-
Line protection	_			-
Version available with				
1-pole and 2-pole breakers	_	•	_	-
3-pole breaker	•			•
4-pole breaker	_			•
Available protection parameters				
I <sub>r</sub> adjustable	_	_		
I <sub>i</sub> adjustable	•	-	-	•
I <sub>r</sub> fixed	_		-	-
I <sub>i</sub> fixed	_			_
I <sub>N</sub> 1)	-			•

<sup>3 3</sup>VA10 only without N protection 3VA11, 3VA12, 3VA13, 3VA14 without, 50% or 100% N protection 50% N protection from In ≥100 A

# Protection functions of the 3VA2 with electronic trip unit

	ETU310M	ETU320	ETU330	ETU340	ETU350	ETU350M	ETU550	ETU550M	ETU560	ETU850	ETU860	ETU860M
	1	LI	LIG	ELISA®	LSI	LSI	LSI	LSI	LSIG	LSI	LS <b>I</b> G	LSIG
Protection												
Starter protection		-	-	-	-	-	-	-	-	-	_	-
Motor protection	-	-	-	-	-		-		-	-	-	
Line protection	-					-		-				-
Generator protection	-			-	-	-		-			-	-
Version available with												
3-pole without external neutral conductor transformer	•	•	-	-	-	-	-	•	-	-	_	-
3-pole with external neutral conductor transformer	-	-	-	-	_	-	•	-	•	•	-	-
4-pole with protected neutral conductor transformer	-	-	-	-	-	-	-	-	-	-	-	-
Available protection parameters												
Characteristic in L range	I <sup>2</sup> t	<b>I</b> ²t	<b>l</b> ²t	I <sup>4</sup> t	l²t	l²t	I²t	<b>I</b> <sup>2</sup> t	I²t	<b>l</b> ²t	I²t	l²t
I <sub>r</sub>	-											
$t_r$ at $6 \times I_r$	-			-		-		-				-
t <sub>c</sub>	-	_	-	-	-		-		-	-	-	
t <sub>p</sub>	-	-	-	-	-	-	-		-	-	_	
Thermal image												
Thermal image can be switched on/off	-	-	-	-	-	-	•	-	•	•	-	-
I <sub>sd</sub>	-	-	-	-								
$t_{sd}$ at $8 \times I_r$	-	-	-	-	-							
Characteristic in S range: I <sup>2</sup> t <sub>sd</sub>	-	-	-	-		-		-			-	-
Characteristic in S range: selectable I <sup>2</sup> t <sub>sd</sub> / t <sub>sd</sub>	-	-	-	-	-	-	•	-	•	•	-	-
$\mathbf{I}_{i}$												
I <sub>N</sub> 1)	-					-		-			-	-
l <sub>g</sub>	-	_		-	-	-	_			-		
$t_q$ at 2 × $I_q$	-	-		-	-	-	-			-		
Characteristic in G range: I <sup>2</sup> t <sub>g</sub>	-	-		-	_	-	-			-	-	
Characteristic in G range: selectable $I^2t_\alpha$ / $t_\alpha$	-	-	•	-	-	-	-	•	-	-	-	•
Ground-fault alarm function	-	-	-	-	-	-	-			-		
Blocking protection	-	-	-	-	-	-	-	-	-	-	-	
ZSI in combination with an EFB external function box	-	•	-	-	-	-	-	•	-	-	-	•

<sup>1)</sup> Available in a version with external current transformer for N conductor or 4-pole breaker

# Online configurator highlights

# siemens.com/lowvoltage/configurators



# 






# www.siemens.com/lowvoltage/3va-configurator and www.siemens.com/lowvoltage/3va27-configurator



# Download the individual edz files for 3VA The configuration is complete. Show on the file product. Selection 3 Persona Selection 3 Not selection for the control of the product of th



# System overview

For a complete and verified configuration of your molded case circuit breaker, please use our online configurator at www.siemens.com/lowvoltage/configurator-3VA

#### **Basic units**





3VA1 for standard applications

3VA2 for selective applications

# Trip unit







Electronic trip unit Electronic trip unit (ETU) with display, and optionally with metering

# Trip unit accessories



24 V module



Communica-

tion module





display

Test device

# Installation type

(ETU)



Fixed-mounted

unit (TMTU)



ಡಡಡ



Draw-out unit, complete kit

dad Plug-in unit, complete kit

# Supplementary accessories













Auxiliary circuit connector

Position feedthrough signaling switch

Cylinder lock adapter

Crank

#### Main conductor connection



connectors

extended





Front bus connectors offset



terminal







terminals

#### Connection accessories



Insulation accessories

2/20

# Auxiliary releases/auxiliary switches



releases



release





switch









Short circuit alarm switch SAS

# Mountable accessories

release







Manual operator

Motorized operating mechanism

Residual current device

# Additional circuit breaker accessories



Cover frame

Adapter for DIN rails

# Mechanical interlocks













Locking device

Sliding bar interlock

Interlocking with rod


Handle interlock using a Bowden cable


Cylinder lock

# Structure of the article numbers

## Basic configuration

For a complete and verified configuration of your molded case circuit breaker, please use our online configurator at www.siemens.com/lowvoltage/configurator-3VA





System overview, page 2/20 Siemens LV 10 · 10/2019 2/23

# Internal accessories

# Auxiliary switches and alarm switches

Configure your molded case circuit breaker easily online at

www.siemens.com/lowvoltage/configurator-3VA 3VA22 3VA12 3VA13 3VA14 3VA15 3VA25 Auxiliary switches AUX Used to signal the position of the main contacts of the molded case circuit breaker • The contacts of the auxiliary switch and the molded case circuit breaker close in unison Width U<sub>e</sub> AC/DC Type L Version НО 7 mm 6 A 240 V/250 V Standard 3VA9988-0AA12 (1 slot) <1 A 24 V/24 V Electronic-3VA9988-0AA13 compatible HP 14 mm 10 A 600 V/250 V Standard 3VA9988-0AA11 (2 slots) Leading changeover switches LCS · Used for load shedding, for example Signal the opening of the main contacts with a lead time of 20 ms in advance of circuit breaker trips Width U<sub>e</sub> AC/DC HQ 7 mm 6 A 240 V/250 V Standard 3VA9988-0AA22 (1 slot) <1 A 24 V/24 V Electronic-3VA9988-0AA23 compatible HP 600 V/250 V Standard 3VA9988-0AA21 14 mm 10 A (2 slots) Trip alarm switches TAS Signal every circuit breaker tripping operation · Are actuated whenever the molded case circuit breaker switches to the TRIP position Width U. AC/DC Type Version 6 A 240 V/250 V Standard 3VA9988-0AB12 HQ 7 mm (1 slot) 24 V/24 V 3VA9988-0AB13 <1 A Electroniccompatible НР 600 V/250 V 3VA9988-0AB11 14 mm 10 A Standard (2 slots) Short circuit alarm switches SAS • Signal tripping operations only if they have been initiated by a short circuit • The tripping operation must be reset by deliberate acknowledgement of the fault before the molded case circuit breaker can be switched to ON again Type Width I<sub>e</sub> U<sub>e</sub> AC/DC Version 7 mm 6 A 240 V/250 V Standard 3VA9988-0AB32 3VA9988-0AB32 3VA9988-0AB34 3VA9988-0AB36 (1 slot) <1 A 24 V/24 V Electronic-3VA9988-0AB33 3VA9988-0AB33 3VA9988-0AB35 3VA9988-0AB37 compatible Electrical alarm switches EAS Are actuated as soon as the main contacts of the molded case circuit breaker open in the event that the breaker is tripped by the ETU Type Width I<sub>e</sub> U<sub>e</sub> AC/DC Version

3VA9988-0AB22

3VA9988-0AB23

(1 slot)

6 A 240 V/250 V Standard

<1 A 24 V/24 V

Electronic-

compatible

# Auxiliary releases

# Configure your molded case circuit breaker easily online at

		ltago/contiguest/	ς ν Ο\/Λ			
www.sieiliei	iis.com/lowvo	ltage/configurato	)1-5VA	3VA10		
					21/420	
				3VA11	3VA20	
				3VA12	3VA21	
				3VA13	3VA22	
				3VA14	3VA23	
				3VA15	3VA24	3VA25
Shunt trips left	STI					
Shalle dips lete	<ul><li>Used for remo breaker</li><li>Have particula</li></ul>	ote-controlled tripping of arly low power consumpt	ion			
_		table for electrical interlo				
	Version	U <sub>e</sub> 50/60 Hz AC	U <sub>e</sub> DC			
2.83.6	Standard	_	12 V		3VA9988-0BL10	
Market		24 V	24 30 V		3VA9988-0BL30	
# 1		48 60 V	48 60 V		3VA9988-0BL31	
		110 127 V	110 127 V		3VA9988-0BL32	
		208 277 V	220 250 V		3VA9988-0BL33	
		380 600 V	_		3VA9988-0BL20	
	Electrical (EI)	_	24 V		3VA9988-0BM10	
Shunt trips flexi						
		ote-controlled tripping of llation	the molded case circuit			
ACTOR .	Version	U <sub>e</sub> 50/60 Hz AC	U <sub>e</sub> DC			
		24 V	_	_	3VA9988-0BA20	-
MEUROS		48 60 V	_	_	3VA9988-0BA21	_
42		110 127 V	_	-	3VA9988-0BA22	_
		208 277 V	_	_	3VA9988-0BA23	_
		380 500 V	_	_	3VA9988-0BA24	_
		600 V	_	_	3VA9988-0BA25	_
Universal releas	es UNI	000 1			34713300 087123	
Oniversal releas						
A STATE OF THE PARTY OF THE PAR	<ul> <li>Combination</li> </ul>	of shunt release and und	ervoltage release			
1333		of shunt release and und				
	<ul><li>Combination</li><li>Version</li></ul>	of shunt release and und U <sub>e</sub> 50/60 Hz AC –	U <sub>e</sub> DC		3VA9908-0BD11	
			U <sub>e</sub> DC 12 V		3VA9908-0BD11 3VA9908-0BD12	
			U <sub>e</sub> <b>DC</b> 12 V 24 V		3VA9908-0BD12	
Undervoltage re	Version		U <sub>e</sub> DC 12 V			
Undervoltage re	Version  eleases UVR  • Trips the mole	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in	U <sub>e</sub> <b>DC</b> 12 V 24 V		3VA9908-0BD12	
Undervoltage re	Version  eleases UVR  • Trips the mole voltage of a n	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in	U <sub>e</sub> DC 12 V 24 V 48 V		3VA9908-0BD12	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in nonitored circuit drops be ltogether	U <sub>e</sub> DC 12 V 24 V 48 V In the event that the rated below a minimum permissible		3VA9908-0BD12	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in nonitored circuit drops be ltogether	U <sub>e</sub> DC 12 V 24 V 48 V  the event that the rated elow a minimum permissible  U <sub>e</sub> DC		3VA9908-0BD12 3VA9908-0BD13	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in nonitored circuit drops be ltogether  U <sub>e</sub> 50/60 Hz AC  -	U <sub>e</sub> DC  12 V  24 V  48 V  In the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in nonitored circuit drops be ltogether	U <sub>e</sub> DC 12 V 24 V 48 V  The event that the rated elow a minimum permissible  U <sub>e</sub> DC 12 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in nonitored circuit drops be ltogether  U <sub>e</sub> 50/60 Hz AC  - 24 V	U <sub>e</sub> DC  12 V  24 V  48 V  The event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V  -  48 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in nonitored circuit drops be ltogether  U <sub>e</sub> 50/60 Hz AC  - 24 V - 48 V	U <sub>e</sub> DC  12 V  24 V  48 V  n the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V  -  48 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB22 3VA9908-0BB21	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in nonitored circuit drops be ltogether  U <sub>e</sub> 50/60 Hz AC  - 24 V - 48 V	U <sub>e</sub> DC 12 V 24 V 48 V  n the event that the rated elow a minimum permissible  U <sub>e</sub> DC 12 V 24 V - 48 V - 60 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB13	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in nonitored circuit drops be ltogether  U <sub>e</sub> 50/60 Hz AC  24 V - 48 V - 60 V	U <sub>e</sub> DC 12 V 24 V 48 V  n the event that the rated elow a minimum permissible  U <sub>e</sub> DC 12 V 24 V - 48 V - 60 V -		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB21 3VA9908-0BB23	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in nonitored circuit drops be ltogether  U <sub>e</sub> 50/60 Hz AC  24 V - 48 V - 60 V 110 V	U <sub>e</sub> DC  12 V  24 V  48 V  n the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V  -  48 V  -  60 V  -  -		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB23 3VA9908-0BB22 3VA9908-0BB23	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in nonitored circuit drops be ltogether  U <sub>e</sub> 50/60 Hz AC  24 V - 48 V - 60 V	U <sub>e</sub> DC  12 V  24 V  48 V  In the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V  -  48 V  -  60 V  -  -  -  -  -		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB24	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in nonitored circuit drops be latogether  U <sub>e</sub> 50/60 Hz AC  24 V - 48 V - 60 V 110 V 120 127 V	U <sub>e</sub> DC  12 V  24 V  48 V  n the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V  -  48 V  -  60 V  -  -		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB24 3VA9908-0BB14	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC	U <sub>e</sub> DC  12 V  24 V  48 V  1 the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V  -  48 V  -  60 V  -  125 127 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB24 3VA9908-0BB24 3VA9908-0BB24	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC  ded case circuit breaker in nonitored circuit drops be latogether  U <sub>e</sub> 50/60 Hz AC  24 V - 48 V - 60 V 110 V 120 127 V	U <sub>e</sub> DC  12 V  24 V  48 V  1 the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V  -  48 V  -  60 V  -  125 127 V  -  220 230 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB24 3VA9908-0BB14	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC	U <sub>e</sub> DC  12 V  24 V  48 V  1 the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V  -  48 V  -  60 V  -  125 127 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB24 3VA9908-0BB24 3VA9908-0BB24	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC	U <sub>e</sub> DC  12 V  24 V  48 V  1 the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V  -  48 V  -  60 V  -  125 127 V  -  220 230 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB13 3VA9908-0BB21 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB24 3VA9908-0BB24 3VA9908-0BB14 3VA9908-0BB15	
Undervoltage re	• Trips the mole voltage of a n limit or fails a	U <sub>e</sub> 50/60 Hz AC	U <sub>e</sub> DC  12 V  24 V  48 V  1 the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V  -  48 V  -  60 V  -  -  125 127 V  -  220 230 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB24 3VA9908-0BB24 3VA9908-0BB14 3VA9908-0BB15 3VA9908-0BB15 3VA9908-0BB15	
	eleases UVR  • Trips the mole voltage of a n limit or fails a Version	U <sub>e</sub> 50/60 Hz AC	U <sub>e</sub> DC  12 V  24 V  48 V  1 the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V  -  48 V  -  60 V  -  -  125 127 V  -  220 230 V  250 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB22 3VA9908-0BB23 3VA9908-0BB24 3VA9908-0BB24 3VA9908-0BB15 3VA9908-0BB15 3VA9908-0BB16 3VA9908-0BB16	
	eleases UVR  • Trips the mole voltage of a n limit or fails a Version	U <sub>e</sub> 50/60 Hz AC	U <sub>e</sub> DC  12 V  24 V  48 V  An the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V   48 V   60 V    125 127 V   220 230 V  250 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB22 3VA9908-0BB23 3VA9908-0BB24 3VA9908-0BB24 3VA9908-0BB15 3VA9908-0BB15 3VA9908-0BB16 3VA9908-0BB16	
	eleases UVR  • Trips the mole voltage of a n limit or fails a Version	U <sub>e</sub> 50/60 Hz AC	U <sub>e</sub> DC  12 V  24 V  48 V  An the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V   48 V   60 V    125 127 V   220 230 V  250 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB24 3VA9908-0BB25 3VA9908-0BB15 3VA9908-0BB15 3VA9908-0BB15 3VA9908-0BB26 3VA9908-0BB26	
	eleases UVR  • Trips the mole voltage of a n limit or fails a Version	U <sub>e</sub> 50/60 Hz AC	U <sub>e</sub> DC  12 V  24 V  48 V  n the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V   48 V   60 V   125 127 V   220 230 V  250 V    U <sub>e</sub> DC  110 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB25 3VA9908-0BB25 3VA9908-0BB25 3VA9908-0BB25 3VA9908-0BB25 3VA9908-0BB25 3VA9908-0BB27	
	eleases UVR  • Trips the mole voltage of a n limit or fails a Version	U <sub>e</sub> 50/60 Hz AC	U <sub>e</sub> DC  12 V  24 V  48 V  An the event that the rated elow a minimum permissible  U <sub>e</sub> DC  12 V  24 V   48 V   60 V    125 127 V   220 230 V  250 V		3VA9908-0BD12 3VA9908-0BD13 3VA9908-0BB10 3VA9908-0BB11 3VA9908-0BB20 3VA9908-0BB12 3VA9908-0BB21 3VA9908-0BB23 3VA9908-0BB23 3VA9908-0BB24 3VA9908-0BB25 3VA9908-0BB15 3VA9908-0BB15 3VA9908-0BB15 3VA9908-0BB26 3VA9908-0BB26	

System overview, page 2/20

# Manual operators

# Configure your molded case circuit breaker easily online at www.siemens.com/lowvoltage/configurator-3VA

		voitageree	3				3VA13	
						3VA20	3VA14	
				3VA10	2)///42	3VA21	3VA23	3VA15
Event meaning				3VA11	3VA12	3VA22	3VA24	3VA25
Front mount	ed rotary operato • Handle	rs						
	<ul><li>For IEC</li><li>Degree of prote</li><li>For 3-pole and 4</li></ul>							
	Version	Illumination kit	Door interlock					
	Standard (gray)	Without	Without	3VA9157-0EK11	3VA9257-0EK11	3VA9267-0EK11	3VA9467-0EK11	3VA9687-0EK11
			With	3VA9157-0EK21	3VA9257-0EK21	3VA9267-0EK21	3VA9467-0EK21	3VA9687-0EK21
		With	Without	3VA9157-0EK13	3VA9257-0EK13	3VA9267-0EK13	3VA9467-0EK13	-
			With	3VA9157-0EK23	3VA9257-0EK23	3VA9267-0EK23	3VA9467-0EK23	-
1	EMERGENCY-	Without	Without	3VA9157-0EK15	3VA9257-0EK15	3VA9267-0EK15	3VA9467-0EK15	3VA9687-0EK15
	STOP (red/yellow)		With	3VA9157-0EK25	3VA9257-0EK25	3VA9267-0EK25	3VA9467-0EK25	3VA9687-0EK25
		With	Without	3VA9157-0EK17	3VA9257-0EK17	3VA9267-0EK17	3VA9467-0EK17	-
			With	3VA9157-0EK27	3VA9257-0EK27	3VA9267-0EK27	3VA9467-0EK27	-
Door mounte	ed rotary operator			ion				
	<ul> <li>Shaft 300 mm (</li> <li>With mounting </li> <li>Handle with ma (100 × 100 mm)</li> <li>Degree of prote</li> <li>For 3-pole and 4</li> </ul>	tolerance compe sking plate 75 × for 3VA15/3VA ction IP65	nsation 75 mm					
	Version	Illumination kit	Door interlock					
(320)	Standard (gray)	Without	With	3VA9157-0FK21	3VA9257-0FK21	3VA9267-0FK21	3VA9467-0FK21	3VA9687-0FK21
		With	With	3VA9157-0FK23	3VA9257-0FK23	3VA9267-0FK23	3VA9467-0FK23	3VA9467-0FK23
(4.00	EMERGENCY-	Without	With	3VA9157-0FK25	3VA9257-0FK25	3VA9267-0FK25	3VA9467-0FK25	3VA9687-0FK25
	STOP (red/yellow)	With	With	3VA9157-0FK27	3VA9257-0FK27	3VA9267-0FK27	3VA9467-0FK27	3VA9467-0FK27
Door mounte	d rotary operator	s without tole	ance compen	sation <mark>new</mark>				
	<ul> <li>Shaft 300 mm (</li> <li>Handle with ma (100 × 100 mm)</li> <li>Degree of protestory</li> <li>For 3-pole and 4</li> </ul>	sking plate 75 × for 3VA15/3VA ction IP65	75 mm					
	Version	Illumination kit	Door interlock					
	Standard (gray)	Without	With	3VA9157-0FK61	3VA9257-0FK61	3VA9267-0FK61	3VA9467-0FK61	3VA9687-0FK61
Door mounte	d rotary operator	s without han	dle					
5	<ul><li>For IEC</li><li>Degree of prote</li><li>For 3-pole and 4</li></ul>							
	Version	Illumination kit	Door interlock					
	With shaft stub (gray)	-	Without	3VA9157-0GK00	3VA9257-0GK00	3VA9267-0GK00	3VA9467-0GK00	3VA9687-0GK00

							3VA13	
						3VA20	3VA14	
				3VA10		3VA21	3VA23	3VA15
				3VA11	3VA12	3VA22	3VA24	3VA25
Side wall mo	unted rotary opei	rators						
1 9	<ul> <li>Rotary operator</li> <li>Handle with ma</li> <li>Degree of prote</li> <li>For 3-pole and 4</li> </ul>	with shaft 300 asking plate 75 a action IP65						
	Version	Mounting bracket	Illumination kit					
	Standard (gray)	Without	Without	3VA9157-0PK11	3VA9257-0PK11	3VA9267-0PK11	3VA9467-0PK11	-
			With	3VA9157-0PK13	3VA9257-0PK13	3VA9267-0PK13	3VA9467-0PK13	-
	EMERGENCY-	Without	Without	3VA9157-0PK15	3VA9257-0PK15	3VA9267-0PK15	3VA9467-0PK15	-
	STOP (red/yellow)		With	3VA9157-0PK17	3VA9257-0PK17	3VA9267-0PK17	3VA9467-0PK17	-
Side wall mo	unted rotary oper	rators with mo	ounting plates					
	<ul> <li>Rotary operator plate for mount</li> <li>Handle with ma</li> <li>Degree of prote</li> <li>For 3-pole and 4</li> </ul>	ing directly on t sking plate 75 s ection IP65	:he side wall					
	Version	Mounting bracket	IIIumination kit					
	Standard (gray)	With	Without	3VA9157-0PK51	3VA9257-0PK51	3VA9267-0PK51	-	-
			With	3VA9157-0PK53	3VA9257-0PK53	3VA9267-0PK53	-	<del>-</del>
	EMERGENCY-	With	Without	3VA9157-0PK55	3VA9257-0PK55	3VA9267-0PK55	-	-
	STOP (red/yellow)		With	3VA9157-0PK57	3VA9257-0PK57	3VA9267-0PK57	-	_
Extended DIN	N rails for N/PE ter	rminals new						
	Version	Rated currer	nt					
	For mounting plate	Up to 250 A		3VA9987-0GL30	3VA9987-0GL30	3VA9987-0GL30	-	-
Auxiliary swi	tch modules for r	otarv operatir	ng mechanisms	new				
	Version	out, operan						
	2× leading to "ON"	,		3VA9257-0GX10	3VA9257-0GX10	3VA9467-0GX10	3VA9467-0GX10	_
	2× leading to "ON"		to "OFF"	_	_		3VA9467-0GX20	_
Mounting ad	apters for side wa			new				
9	Version		у продатого					
	Necessary accesso rotary operators, if modules are used			3VA9257-0GX01	3VA9257-0GX01	3VA9467-0GX01	-	-
Masking plat	es, standard <mark>new</mark>	1						
	Version							
	Necessary accesso operators and 3VA operators, if 3VA9 modules are used	side wall mour 0GX.0 auxilia	nted rotary	8UD1900-0BB01	8UD1900-0BB01	8UD1900-0BB01	8UD1900-0BB01	-
Masking plat	es, EMERGENCY S	STOP new						
	Version							
	Necessary accesso operators and 3VA operators, if 3VA9 modules are used	side wall mour	nted rotary	8UD1900-0BB05	8UD1900-0BB05	8UD1900-0BB05	8UD1900-0BB05	<del>-</del>

 System overview, page 2/20
 Siemens LV 10 · 10/2019
 2/27

# Manual operators

# Configure your molded case circuit breaker easily online at www.siemens.com/lowvoltage/configurator-3VA

		voltage/comigurator	3VA10 3VA11	3VA12	3VA20 3VA21 3VA22	3VA13 3VA14 3VA23 3VA24	3VA15 3VA25
Supplementa	ry handles for do	or mounted rotary operators	5				
100	For operation w	hen cabinet door is open					
	Version						
	Standard (gray)		3VA9287-0GC01	3VA9287-0GC01	3VA9487-0GC01	3VA9487-0GC11	3VA9687-0GC01
	EMERGENCY- STOP (red/yellow)		3VA9287-0GC05	3VA9287-0GC05	3VA9487-0GC05	3VA9487-0GC15	3VA9687-0GC05
Handles							
	With masking pl	ate					
	Version	Tolerance compensation					
	Standard (gray)	With		8UD1721-0AB21		8UD1731-0AB21	8UD1741-0AB21
		Without		8UD1721-0AB11		8UD1731-0AB11	8UD1741-0AB11
	EMERGENCY-	With		8UD1721-0AB25		8UD1731-0AB25	8UD1741-0AB25
	STOP (red/yellow)	Without		8UD1721-0AB15		8UD1731-0AB15	8UD1741-0AB15
Handle exter	nsions						
		le lever extension is already scope of supply of the					
			-	_	-	3VA9487-0SC10	3VA9987-0SC10
Shafts							
//	Versions	Length					
	8 × 8 mm	300 mm		8UD190	0-2WA00		_
		600 mm			0-2WB00		_
fill .	12 × 12 mm	300 mm	_	_	_	_	8UD1900-4WA00
77	12 12 11111	600 mm	_	_	_	_	8UD1900-4WB00
Adapters for	shafts	330 11111					0001700 111500
ridapters for	Versions	Purpose					
	8 × 8 mm	With door mounted rotary operator and side wall mounted rotary operator		8UD190	0-2DA00		-
	12 × 12 mm	For door mounted rotary operator	<del>-</del>	-	-	-	8UD1900-4DA00
Door couplin	as						
200. 600,51111	Versions						
	8 × 8 mm			8UD190	0-2HA00		-
	12 × 12 mm		-	-	-	-	8UD1900-4HA00

					3VA13	
				3VA20	3VA14	
		3VA10		3VA21	3VA23	3VA15
		3VA11	3VA12	3VA22	3VA24	3VA25
Mounting to	lerance compensations					
	Versions					
	8 × 8 mm		8UD190	0-2GA00		-
	12 × 12 mm	-	-	-	-	8UD1900-4GA00
Fixing brack	ets for shafts					
44.						
		3VA928	7-0GA80	3VA948	7-0GA80	3VA9687-0GA80
Variable dept	h adapters					
	Size					
	8 × 8 mm		3VA948	7-0GB10		-

System overview, page 2/20 Siemens LV 10 · 10/2019 2/29

# Manual operators

#### Configure your molded case circuit breaker easily online at

www.siemens.com/lowvoltage/configurator-3VA 3VA22 3VA13 3VA14 3VA15 3VA25 3VA24 Labeling plates for manual operators 3VA9087-0SX10 Illumination kits for manual operators • 24 V DC voltage Version Rated current Front rotary operating 100 ... 250 A 8UD1900-0KA10 mechanism 100 ... 630 A 8UD1900-0KA20 8UD1900-0KA20 630 ... 1000 A 8UD1900-0KA30 8UD1900-0KA30 Door mounted rotary operator 100 ... 630 A 8UD1900-0KA20 8UD1900-0KA20 8UD1900-0KA20 8UD1900-0KA20 and side wall mounted rotary 630 ... 1000 A 8UD1900-0KA30 operator Cylinder locks (type Kaba), standard masking plates **Purpose** For door mounted rotary 8UD1900-0MB01 8UD1900-0MB01 8UD1900-0MB01 operator and side wall 8UD1900-0NB01 8UD1900-0NB01 8UD1900-0NB01 mounted rotary operator 8UD1900-0PB01 8UD1900-0PB01 8UD1900-0PB01 (in the masking plate) 8UD1900-0QB01 8UD1900-0QB01 8UD1900-0QB01 Cylinder locks (type Kaba), EMERGENCY OFF masking plates **Purpose** Key For door mounted rotary 8UD1900-0MB05 8UD1900-0MB05 8UD1900-0MB05 operator and side wall 8UD1900-0NB05 8UD1900-0NB05 8UD1900-0NB05 mounted rotary operator 8UD1900-0PB05 8UD1900-0PB05 8UD1900-0PB05 (in the masking plate) 4 8UD1900-0QB05 8UD1900-0QB05 8UD1900-0QB05 Cylinder locks (type Ronis) Includes a lock with 2 kevs For locking or interlocking For installation in all rotary operators · For mounting in the adapter kit for the accessories compartment Note: The cylinder lock adapter for rotary operators is also needed for locking or interlocking circuit breakers via rotary 3VA9980-0VL10 3VA9980-0VL30 3VA9980-0VL40 Cylinder lock adapters for rotary operators • To mount the cylinder lock in the rotary operator (also possible with door mounted rotary operator and side wall mounted rotary operator) Rated current 100 ... 630 A 3VA9980-0LF20 3VA9980-0LF20 3VA9980-0LF20

3VA9680-0LF20

3VA9680-0LF20

1000 A

System overview, page 2/20

# Motor operators

#### Configure your molded case circuit breaker easily online at

www.siemens.com/lowvoltage/configurator-3VA

#### Side mounted motor operators (MO310)



<ul> <li>Cover size 45 m</li> </ul>	m					
Addressable via control signals	Isolating features in accordance with IEC/EN 60947-1	Make time, t for 3VA1	typically for 3VA2	Break time, for 3VA1	typically for 3VA2	Rated operational power
•	•	<300 ms	-	<300 ms	-	250 W, max. 500 W

#### Motor operators without stored energy operators (MO320)



Addressable via	Isolating features in	Make time, typ	oically	Break time, ty	pically	Rated
control signals	accordance with IEC/EN 60947-1	for 3VA1	for 3VA2	for 3VA1	for 3VA2	operational power
•	•	<800 ms (160 A, 250A)	<1000 ms (250 A), <1700 ms (630 A)	<800 ms (160 A, 250A)	<1000 ms (250 A), <1400 ms (630 A)	250 W, max. 500 W

#### Motor operators with stored energy operators (SEO520)

- Synchronizable remote operating mechanism with optional communication link
- Has two spring assemblies that are used to switch the 3VA2 molded case circuit breaker on and off quickly. This new principle in the MCCB
  area ensures fast, reliable and easily controllable switching sequences, especially in load transfer switching applications.
- The connection with the COM060 communication module, via a plug-in connection, integrates the SEO520 into the communication environment of the 3VA molded case circuit breakers and ensures that the molded case circuit breaker can also be switched via the supported communication networks and the powerconfig and powermanager software packages.
- Note: On account of the fast switching times, the SEO520 cannot be used with a leading changeover switch LCS.



Addressable via	Isolating features in	Make time, ty	Make time, typically		Break time, typically		
control signals	accordance with IEC/EN 60947-1	for 3VA1	for 3VA2	for 3VA1	for 3VA2	operational power	
•	•	-	<80 ms	-	<80 ms	300 W, max. 500 W (60 ms)	

#### Mechanical operating cycles counters (for installation in the SEO520)



MountingArticle No.For installation in the SEO5203VA9987-0HX10

#### Cylinder lock adapters for SEO520



MountingArticle No.For installation of cylinder locks in the SEO5203VA9980-0LF30

#### Cylinder locks (type Ronis)



- Includes a lock with 2 keys
- For locking the operating mode (Manual/Auto/Lock) of the SEO520

Key	Article No.
1	3VA9980-0VL10
3	3VA9980-0VL30
4	3VA9980-0VL40

				3VA20	3VA13 3VA14
				3VA21	3VA23
		3VA11	3VA12	3VA22	3VA24
Rated control supply voltage	With communication				
42 60 V AC, 24 60 V DC	-	3VA9117-0НВ10	-	-	-
110 230 V AC, 110 250 V DC	-	3VA9117-0HB20	-	-	-
Rated control supply voltage	With communication				
24 60 V DC	_	3VA9157-0HA10	3VA9257-0HA10	3VA9267-0HA10	3VA9467-0HA10
110 230 V AC, 110 250 V DC	-	3VA9157-0HA20	3VA9257-0HA20	3VA9267-0HA20	3VA9467-0HA20
Rated control supply voltage	With communication				
24 V DC	-	-	-	3VA9267-0HC10	-
42 60 V AC/DC	-	_	-	3VA9267-0HC20	-
110 230 V AC, 110 250 V DC	-	_	-	3VA9267-0HC30	-
24 V DC	Yes	-	-	3VA9267-0HC15	-
110 230 V AC, 110 250 V DC	Yes	-	-	3VA9267-0HC35	-



### Reset mode

All motor operators have the following reset modes: Reset mode 1: Automatic reset Reset mode 2: Reset via OFF-signal

The motor operator with SEO520 stored energy operator additionally has: Reset mode 3: Reset via OFF-signal with additional acknowledge signal

# Connection technology



- For mounting onto the circuit breaker
- For mounting onto withdrawable and plug-in units

Configure your molded case circuit breaker easily online at www.siemens.com/lowvoltage/configurator-3VA

						3VA10	
						3VA11	
Box terminals							
	Conn	ection options	Scope of supply	Copper stranded			
湖湖湖	0	<b>2</b>	3 single terminals	1.5 70 mm <sup>2</sup>		3VA9153-0JA11	
CONTRACTOR OF THE PARTY OF THE				6 120 mm²		-	
				25 185 mm²		-	
				50 185 mm²		-	
				35 300 mm²		<u> </u>	
	0	<b>2</b>	4 single terminals	1.5 70 mm <sup>2</sup>		3VA9154-0JA11	
ST ST ST ST				6 120 mm²		-	
				25 185 mm²		-	
				50 185 mm²		-	
				35 300 mm²		-	
Nut keeper units							
	Conn	ection options	Scope of supply	Max. tap width	Max. tap thickness		
	0	<b>2</b>	3 single terminals	17 mm	6.5 mm	3VA9113-0QA00	
0.0101				25 mm	8 mm	_	
				35 mm	10 mm	-	
			Nut keeper kit for 3-pole	50 mm	25 mm	-	
			breakers, 1 terminal cover				
7700	0	<b>2</b>	4 single terminals	17 mm	6.5 mm	3VA9114-0QA00	
20.0.0				25 mm	8 mm	-	3VA9114-0QA00 - - -
				35 mm	10 mm	_	
			Nut keeper kit for 4-pole	50 mm	28 mm	-	
Circular conducto	r tormin	als 1 cablo	breakers, 1 terminal cover			_	
Circular conducto		ection options	Scope of supply	Copper/aluminum			
	Colli	ection options	scope of supply	stranded			
A 100 min	0	0	3 single terminals	1.5 10 mm <sup>2</sup> new		3VA9113-0JB10	
ก ก ก				1.5 50 mm <sup>2</sup>		_	
				10 95 mm²		3VA9113-0JB11	
				16 185 mm²		_	
				35 185 mm²		_	
				50 300 mm²		_	
AND 1819 1819	0	9	4 single terminals	1.5 10 mm² new		3VA9114-0JB10	
व व व व				1.5 50 mm²		_	
				10 95 mm²		3VA9114-0JB11	
				16 185 mm²		_	
				35 185 mm²		_	
				50 300 mm²			

 $<sup>^{9}</sup>$  Only permitted up to 400 A  $^{2}$  Maximum current-carrying capacity of aluminum cables 310 A Maximum current-carrying capacity of aluminum cables 310 A

	2)/4.20	3VA13	
	3VA20	3VA14	2)/445
	3VA21	3VA23	3VA15
3VA12	3VA22	3VA24	3VA25
-	-	-	-
3VA9253-0JA11	3VA9163-0JA12	-	-
_	3VA9263-0JA12	-	-
3VA9253-0JA12	-	-	-
<del>-</del>	-	3VA9483-0JA13 1)	-
	-	-	-
3VA9254-0JA11	3VA9164-0JA12	-	-
-	3VA9264-0JA12	-	-
3VA9254-0JA12	-	-	_
_	-	3VA9484-0JA13 1)	-
-	_	-	_
3VA9213-0QA00	3VA9203-0QA00	-	_
_	-	3VA9403-0QA00	_
-	-	-	3VA9603-0QA00
-	-	-	-
3VA9214-0QA00	3VA9204-0QA00	-	-
-	-	3VA9404-0QA00	-
-	-	-	3VA9604-0QA00
-	-	-	-
-	3VA9103-0JB11	-	-
-	-	-	-
-	3VA9263-0JB12	-	-
3VA9253-0JB12	-	-	-
_	-	3VA9383-0JB13 <sup>2)</sup>	
-	3VA9104-0JB11	-	-
-	-	-	-
-	3VA9264-0JB12	-	-
3VA9254-0JB12	-	-	-
		3VA9384-0JB13 2)	

System overview, page 2/20 Siemens LV 10 · 10/2019 2/35

# Connection technology



- For mounting onto the circuit breaker
- For mounting onto withdrawable and plug-in units

Configure your molded case circuit breaker easily online at www.siemens.com/lowvoltage/configurator-3VA

						3VA10
						3VA10
r conducto	r termin	als with auxiliary	conductor terminals, 1 ca	ble <sup>2)</sup>		JVATT
		ection options	Scope of supply	Copper/aluminum stranded		
1.00	0	6	3 single terminals	1.5 10 mm² new		3VA9113-0JG10
5)				1.5 50 mm²		_
				10 95 mm²		3VA9113-0JG11
				16 185 mm²		_
				35 185 mm²		-
				50 300 mm <sup>2</sup>		-
-	0	0	4 single terminals	1.5 10 mm <sup>2</sup> new		3VA9114-0JG10
តាតា				1.5 50 mm²		-
				10 95 mm²		3VA9114-0JG11
				16 185 mm²		-
				35 185 mm²		-
				50 300 mm²		-
r conducto	r termina	als, 2 cables				
	Conn	ection options	Scope of supply	Copper/aluminum stranded	Aux. conductor terminal	
	0	2	3 single terminals,	120 300 mm <sup>2</sup>	No	-
l son			1 short terminal cover		Yes <sup>2)</sup>	-
and a						
1	0	2	4 single terminals,	120 300 mm²	No	-
m			1 short terminal cover		Yes <sup>2)</sup>	-
100						
r conducto		als, 3 cables				
	Conn	ection options	Scope of supply	Copper/aluminum stranded	Aux. conductor terminal	
	0	2	3 single terminals,	120 185 mm²	No	-
			1 short terminal cover		Yes <sup>2)</sup>	-
Tales						
	0	<b>@</b>	4 single terminals,	120 185 mm²	No	-
में हत			1 short terminal cover		Yes <sup>2)</sup>	-
		1.6				
ry conduct		nals for box term	inais 2)			
	Versi					2)/A0110 0W/D00
7		-mounted n and draw-out ted	hnology			3VA9110-0WB00 3VA9150-0WB00
,	Plug-I	n and draw-out tec	mnology			24V3120-0MP00
ry conduct	tor termi	nals for busbars 2	)			
	Versi	on				
	Fixed	-mounted				3VA9110-0WC00
	Plug-i	n and draw-out ted	hnology			3VA9150-0WC00

Maximum current-carrying capacity of copper cables 380 A Maximum current-carrying capacity of aluminum cables 310 A
 Maximum current-carrying capacity 15 A Maximum cable connection up to 2.5 mm²

2/37

	3VA20	3VA13 3VA14	27/445
3VA12	3VA21 3VA22	3VA23 3VA24	3VA15 3VA25
37712	31/122	37/121	37723
-	-	-	-
-	3VA9103-0JG11	-	-
- -	-	-	-
3VA9253-0JG12	3VA9263-0JG12 -	_	-
- -	_	3VA9383-0JG13 <sup>1)</sup>	_
		0111000000000	
<del>-</del>	3VA9104-0JG11	-	-
-	-	-	-
-	3VA9264-0JG12	-	-
3VA9254-0JG12	-	-	-
-	-	3VA9384-0JG13 1)	-
-	-	-	3VA9503-0JB23
-	<del>-</del>	-	3VA9503-0JG23
-		_	3VA9504-0JB23
	<del>-</del>		3VA9504-0JG23
			30703301 03023
-	-	-	3VA9503-0JB32
_	_	_	3VA9503-0JG32
-	-	-	3VA9504-0JB32
-	-	-	3VA9504-0JG32
3VA9200-0WB00	3VA9200-0WB00	3VA9480-0WB00	_
3VA9280-0WB00	3VA9200-0WB00	3VA9480-0WB00	_
347.5200 011000	547.5200 044000	377.5 100 011500	
3VA9200-0WC00	3VA9200-0WC00	3VA9480-0WC00	-
3VA9280-0WC00	3VA9280-0WC00	3VA9480-0WC00	_

System overview, page 2/20 Siemens LV 10 · 10/2019

# Connection technology



- For mounting onto the circuit breaker
- For mounting onto withdrawable and plug-in units

Configure your molded case circuit breaker easily online at

www.siemens.com/lowvoltage/configurator-3VA

Front bus connec	tors extended					
	Number of poles	Conne	ection options	Scope of supply	Max. tap width	Max. tap thickness
0	1P	0	-	1 busbar connection piece	22 mm	8 mm
0						
44	3P	0	2	3 single terminals,	22 mm	8 mm
				2 phase barriers	32 mm	10 mm
					40 mm	12.5 mm
110					50 mm	28 mm
444	4P	0	0	4 single terminals,	22 mm	8 mm
				3 phase barriers	32 mm	10 mm
					40 mm	12.5 mm
<b>###</b>					50 mm	28 mm
Front bus connec	tors offset					
	<ul> <li>Distance betwee</li> <li>100/160 A =</li> <li>250 A = 45 m</li> <li>400/630 A =</li> </ul>	35 mm nm	enters:			
	Number of poles	Conne	ection options	Scope of supply	Max. tap width	Max. tap thickness
44	3P	0	<b>2</b>	3 single terminals,	30 mm	8 mm
				2 phase barriers	35 mm	10 mm
					60 mm	12.5 mm
444	4P	0	2	4 single terminals,	30 mm	8 mm
888				3 phase barriers	35 mm	10 mm
110					60 mm	12.5 mm
Bus connectors e	dgewise					
	Number of poles	Conne	ection options	Scope of supply	Max. tap width	Max. tap thickness
44	3P	0	<b>2</b>	3 single terminals,	20 mm	6 mm
				2 phase barriers	25 mm	7 mm
<b>J</b> J					40 mm	8 mm
444	4P	0	<b>2</b>	4 single terminals,	20 mm	6 mm
				3 phase barriers	25 mm	7 mm
111					40 mm	8 mm
Nut keeper units	, right-angled <sup>1)</sup>					
	Number of poles	Conne	ection options		Max. tap width	Max. tap thickness
44	3P	0	2	3 single terminals,	22 mm	8 mm
				2 phase barriers	32 mm	10 mm
***					40 mm	12.5 mm
444	4P	0	<b>2</b>	4 single terminals,	22 mm	8 mm
				3 phase barriers	32 mm	10 mm
777					40 mm	12.5 mm
- IN [2]						

 $^{1)}$  Can only be connected to breaker side N, 1, 3, 5

			3VA13	
		3VA20	3VA14	
3VA10		3VA21	3VA23	3VA15
3VA11	3VA12	3VA22	3VA24	3VA25
3VA9151-0QB00	-	-	-	-
3VA9153 <b>-</b> 0QB00	-	-	-	-
_	3VA9253-0QB00	3VA9263-0QB00	-	-
	-	-	3VA9483-0QB00	- 2VA0603 00P00
_	<del>-</del>	-	-	3VA9603-0QB00
3VA9154-0QB00	-	_	-	-
-	3VA9254-0QB00	3VA9264-0QB00	-	-
_	-	-	3VA9484-0QB00	-
-	-	<del>-</del>	-	3VA9604-0QB00
3VA9153-0QC00	-	-	-	-
-	3VA9253-0QC00	3VA9263-0QC00	-	-
-	-	-	3VA9483-0QC00	-
3VA9154-0QC00	_		_	_
-	3VA9254-0QC00	3VA9264-0QC00	_	_
-	- `	_ `	3VA9484-0QC00	_
3VA9153-0QD00	-	-	_	-
-	3VA9253-0QD00	3VA9263-0QD00	_	_
-	- 1	- '	3VA9483-0QD00	-
3VA9154-0QD00	-			
3VA9154-0QD00 -	3VA9254-0QD00	3VA9264-0QD00	<u>-</u>	_
	-	-	3VA9484-0QD00	_
3VA9113-0QG00	-	-	_	
- 3VA9113-0QG00	3VA9213-0QG00	3VA9223-0QG00	_ _	_
<del>-</del>	-	-	3VA9403-0QG00	-
			,	
01/4				
3VA9114-0QG00	-	-	-	-
-	3VA9214-0QG00	3VA9224-0QG00	-	-
<del>-</del>	-	-	3VA9404-0QG00	-

# Connection technology



- For mounting onto the circuit breaker
- For mounting onto withdrawable and plug-in units

Configure your molded case circuit breaker easily online at www.siemens.com/lowvoltage/configurator-3VA

Rear connection st	uds flat			
	Number of poles	Conne	ction options	Scope of supply
	1P	0	<b>2</b>	1 short connection stud flat
				1 long connection stud flat
- D	3P	0	2	2 short connection studs flat,
4				1 long connection stud flat
D_ D	4P	0	<b>2</b>	2 short connection studs flat,
444				2 long connection studs flat
Rear connection st	uds round			
	Number of poles	Conne	ction options	Scope of supply
	1P	0	2	1 short connection stud round
				1 long connection stud round
a 🔊.	3P	0	<b>2</b>	1 long connection stud round,
				2 short connection studs round
A. A	4P	0	<b>2</b>	2 long connection studs round,
				2 short connection studs round

			3VA13	
		3VA20	3VA14	
3VA10		3VA21	3VA23	3VA15
3VA11	3VA12	3VA22	3VA24	3VA25
3VA9111-0QE10	3VA9211-0QE10	3VA9201-0QE10	3VA9401-0QE10	-
3VA9111-0QE20	3VA9211-0QE20	3VA9201-0QE20	3VA9401-0QE20	-
3VA9113-0QE00	3VA9213-0QE00	3VA9203-0QE00	3VA9403-0QE00	-
3VA9114-0QE00	3VA9214-0QE00	3VA9204-0QE00	3VA9404-0QE00	-
3VA9111-0QF10	3VA9211-0QF10	3VA9201-0QF10	3VA9401-0QF10	-
3VA9111-0QF20	3VA9211-0QF20	3VA9201-0QF20	3VA9401-0QF20	-
3VA9113-0QF00	3VA9213-0QF00	3VA9203-0QF00	3VA9403-0QF00	-
3VA9114-0QF00	3VA9214-0QF00	3VA9204-0QF00	3VA9404-0QF00	-

# Connection technology



- For mounting onto the circuit breaker
- For mounting onto withdrawable and plug-in units

Configure your molded case circuit breaker easily online at

www.siemens.com/lowvoltage/configurator-3VA

Circular condu	ctor terminals, 2P				
	Connection options	Scope of supply	Number of cables	Copper/aluminum stranded	Aux. conductor terminal
-	0 -	2 single terminals,	1	25 150 mm²	Yes 1)
99		1 extended terminal cover,			No
99		1 insulation plate	6	1.5 35 mm²	No
Circular condu	ctor terminals, 3P				
	Connection options	Scope of supply	Number of cables	Copper/aluminum stranded	Aux. conductor terminal
200	0 -	3 single terminals,	1	25 150 mm²	Yes 1)
<u> </u>		1 extended terminal cover, 1 insulation plate			No
學學與				50 240 mm²	Yes 1)
					No
			2	25 150 mm²	Yes 1)
					No
				70 300 mm²	Yes 1)
					No
			4	120 240 mm²	Yes 1)
					No
			6	1.5 35 mm²	No
	- @	3 single terminals,	1	25 150 mm²	Yes 1)
		1 extended terminal cover, 1 insulation plate		50 240 mm²	Yes 1)
		i ilisulation plate	2	25 150 mm²	Yes <sup>1)</sup>
				70 300 mm²	Yes <sup>1)</sup>
			6	1.5 35 mm²	No
Circular condu	ctor terminals, 4P				
	Connection options	Scope of supply	Number of cables	Copper/aluminum stranded	Aux. conductor terminal
333-	0 -	4 single terminals,	1	25 150 mm²	Yes 1)
인민인		1 extended terminal cover,			No
9999		1 insulation plate		50 240 mm²	Yes 1)
					No
			2	25 150 mm²	Yes <sup>1)</sup>
					No
				70 300 mm²	Yes 1)
					No
			4	120 240 mm²	Yes 1)
					No
			6	1.5 35 mm²	No
	- @	4 single terminals,	1	25 150 mm²	Yes 1)
		1 extended terminal cover, 1 insulation plate		50 240 mm²	Yes <sup>1)</sup>
		i insulation plate	2	25 150 mm²	Yes 1)
				70 300 mm²	Yes 1)
			6	1.5 35 mm²	No
1) Maximum curron	t carrying capacity 15 A				

Maximum current-carrying capacity 15 A Maximum cable connection up to 2.5 mm²

			3VA13	
		3VA20	3VA14	
3VA10		3VA21	3VA23	3VA15
3VA10	3VA12	3VA21	3VA23 3VA24	3VA15
SVATI	SVATZ	SVAZZ	3 VA24	SVAZS
3VA9112 <b>-</b> 0JC12	-	-	-	-
3VA9112-0JJ12	-		-	<del>-</del>
3VA9112 <b>-</b> 0JF60	_	-	-	-
3VA9113-0JC12	-	-	-	-
3VA9113-0JJ12	-	-	-	-
<del>-</del>	3VA9213-0JC13	3VA9223-0JC13	-	-
<del>-</del>	3VA9213-0JJ13	3VA9223-0JJ13	-	-
_	3VA9213-0JC22	3VA9223-0JC22	-	-
<del>-</del>	3VA9213-0JJ22	3VA9223-0JJ22	-	-
_	-	-	3VA9403-0JC23	-
<del>-</del>	-	<del>-</del>	3VA9403-0JJ23	_
<del>-</del>	-	-	-	3VA9603-0JC43
_	-	_	-	3VA9603-0JJ43
3VA9113-0JF60	3VA9213-0JF60	3VA9223-0JF60	3VA9303-0JF60	_
3VA9153-0JC12	_	_	-	_
_	3VA9253-0JC13	3VA9263-0JC13	_	_
_	3VA9253-0JC22	3VA9263-0JC22	_	_
<u>-</u>	_	_	3VA9483-0JC23	_
3VA9153-0JF60	3VA9253-0JF60	3VA9263-0JF60	3VA9383-0JF60	_
377,3133 637 66	347 (3233 031 00	34713203 037 00	3477303 037 00	
3VA9114-0JC12	_	-	_	_
3VA9114-0JJ12	_	_	_	_
<u>-</u>	3VA9214-0JC13	3VA9224-0JC13	_	_
_	3VA9214-0JJ13	3VA9224-0JJ13	_	_
	3VA9214-0JC22	3VA9224-0JC22	_	_
<u>_</u>	3VA9214-0JJ22	3VA9224-0JJ22	_	_
	-		3VA9404-0JC23	
	_	-	3VA9404-0JJ23	_
	_	_		21/40604 01043
_	-	-	-	3VA9604-0JC43
- 2VA0114 0IEC0	- 2VA0214 0JEC0	- 2\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	- 2)/40204 0JEC0	3VA9604-0JJ43
3VA9114-0JF60	3VA9214-0JF60	3VA9224-0JF60	3VA9304-0JF60	
3VA9154-0JC12	-	-	-	_
=	3VA9254-0JC13	3VA9264-0JC13	-	_
<del>-</del>	3VA9254-0JC22	3VA9264-0JC22	-	-
<del>-</del>	-	<del>-</del>	3VA9484-0JC23	-
3VA9154-0JF60	3VA9254-0JF60	3VA9264-0JF60	3VA9384-0JF60	-

Sigmens LV 10 · 10/2019 2/43

# Connection technology



- For mounting onto the circuit breaker
- For mounting onto withdrawable and plug-in units

Configure your molded case circuit breaker easily online at www.siemens.com/lowvoltage/configurator-3VA

<b>?</b>	Pecially for fixed r Version Short  Extended 1)  Broadened 1)	Number of poles  1P  2P  3P  4P  2P  3P  4P  4P	Mour	ting location	3VA9111-0WD10 3VA9111-0WD20 3VA9111-0WD30 3VA9111-0WD40 3VA9111-0WF20 3VA9111-0WF40  3VA9111-0WF40	3VA11  3VA9111-0WD10 3VA9111-0WD20 3VA9111-0WD30 3VA9111-0WD40 3VA9111-0WF30 3VA9111-0WF40  3VA9111-0WF40
<b>?</b>	Version Short  Extended 1)  Broadened 1)	Number of poles  1P  2P  3P  4P  2P  3P  4P	0 0 0 0 0 0 0	- - - - -	3VA9111-0WD20 3VA9111-0WD30 3VA9111-0WD40 3VA9111-0WF20 3VA9111-0WF30 3VA9111-0WF40	3VA9111-0WD20 3VA9111-0WD30 3VA9111-0WD40 3VA9111-0WF20 3VA9111-0WF40
vers s	Extended 1)  Broadened 1)	1P 2P 3P 4P 2P 3P 4P	0 0 0 0 0 0 0	- - - - -	3VA9111-0WD20 3VA9111-0WD30 3VA9111-0WD40 3VA9111-0WF20 3VA9111-0WF30 3VA9111-0WF40	3VA9111-0WD20 3VA9111-0WD30 3VA9111-0WD40 3VA9111-0WF20 3VA9111-0WF40
rs s	Extended 1)  Broadened 1)	2P 3P 4P 2P 3P 4P	0 0 0 0 0	- - - -	3VA9111-0WD20 3VA9111-0WD30 3VA9111-0WD40 3VA9111-0WF20 3VA9111-0WF30 3VA9111-0WF40	3VA9111-0WD20 3VA9111-0WD30 3VA9111-0WD40 3VA9111-0WF20 3VA9111-0WF40
5 S	Broadened 1)	3P 4P 2P 3P 4P	0 0 0 0 0	- - - -	3VA9111-0WD30 3VA9111-0WD40 3VA9111-0WF20 3VA9111-0WF30 3VA9111-0WF40	3VA9111-0WD30 3VA9111-0WD40 3VA9111-0WF20 3VA9111-0WF40
5 S	Broadened 1)	4P 2P 3P 4P	0 0 0 0	- - -	3VA9111-0WD40 3VA9111-0WF20 3VA9111-0WF30 3VA9111-0WF40	3VA9111-0WD40 3VA9111-0WF20 3VA9111-0WF30 3VA9111-0WF40
S	Broadened 1)	2P 3P 4P	0 0 0	- - -	3VA9111-0WF20 3VA9111-0WF30 3VA9111-0WF40	3VA9111-0WF20 3VA9111-0WF30 3VA9111-0WF40
S	Broadened 1)	3P 4P 3P	0	-	3VA9111-0WF30 3VA9111-0WF40	3VA9111-0WF30 3VA9111-0WF40
S		4P 3P	0	-	3VA9111-0WF40	3VA9111-0WF40
S		3P	0	-		
S				-	3VA9111-0WG30	3VA9111-0WG30
S	necially for plug-in	4P	0	-		
s	necially for plug-is				3VA9111-0WG40	3VA9111-0WG40
	To provide circu	n and draw-out units (suit breaker touch protection of the molded case circuit	on	rt)	_	
		o the molded case circuit pe of supply: Cover for th		and outgoing terminal		
	Version	Number of poles		iting location		
	Short	3P	0	-	3VA9113-0KB01	3VA9113-0KB01
		4P	0	_	3VA9114-0KB01	3VA9114-0KB01
	or plug-in or draw- • For touch prote	ection in the termination a	area		_	
	of the plug-in o	or draw-out socket onto the plug-in or draw-c		t		
	Version	Number of poles	Mour	ting location		
	Short	3P	-	<b>2</b>	-	3VA9153-0KB03
		4P	-	<b>2</b>	-	3VA9154-0KB03
	Extended 1)	3P		<b>2</b>		3VA9153-0KB04
	Exterioca	-		<u> </u>	_	3VA9154-0KB04
			_	· ·	_	3VA9104-0C16
	Broadened 1)	3P	-	<b>2</b>	-	3VA9153-0KB05
		4P	-	<b>2</b>	-	3VA9154-0KB05
5				e 1 e		
	<b>Version</b> Standard	Number of poles 2P		ting location	21/40111 01/120	2\/\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\
	Stanuaru		0		3VA9111-0WJ20	3VA9111-0WJ20
		3P	0	-	3VA9111-0WJ30	3VA9111-0WJ30
		4P	0	-	3VA9111-0WJ40	3VA9111-0WJ40
	Broadened	3P	0	-	3VA9111-0WK30	3VA9111-0WK30
		4P	0	-	3VA9111-0WK40	3VA9111-0WK40

	21/4.20	3VA13	
	3VA20	3VA14	2)///15
21/412	3VA21	3VA23	3VA15
3VA12	3VA22	3VA24	3VA25
-	-	-	-
-	_	_	_
3VA9211-0WD30	3VA9221-0WD30	3VA9481-0WD30	3VA9601-0WD30
3VA9211-0WD40	3VA9221-0WD40	3VA9481-0WD40	3VA9601-0WD40
_	_	_	_
3VA9211-0WF30	3VA9221-0WF30	3VA9481-0WF30	-
3VA9211-0WF40	3VA9221-0WF40	3VA9481-0WF40	_
3VA9211-0WG30	3VA9221-0WG30	3VA9401-0WG30	_
3VA9211-0WG40	3VA9221-0WG40	3VA9401-0WG40	_
3VA9213 <b>-</b> 0KB01	3VA9123-0KB01	3VA9353-0KB01	_
3VA9214-0KB01	3VA9124-0KB01	3VA9354-0KB01	_
37//3214 0/(001	34//3124 0/(001	3777337 00001	
21/40252 0//002	20/40162 0//002	21/40252 01/002	
3VA9253-0KB03	3VA9163-0KB03	3VA9353-0KB03	-
3VA9254-0KB03	3VA9164-0KB03	3VA9354-0KB03	-
3VA9253 <b>-</b> 0KB04	3VA9163-0KB04	3VA9353-0KB04	-
3VA9254-0KB04	3VA9164-0KB04	3VA9354-0KB04	-
3VA9253 <b>-</b> 0KB05	3VA9163-0KB05	3VA9353-0KB05	-
3VA9254-0KB05	3VA9164-0KB05	3VA9354-0KB05	-
-	-	-	<del>-</del>
3VA9211-0WJ30	3VA9221-0WJ30	3VA9481-0WJ30	-
3VA9211-0WJ40	3VA9221-0WJ40	3VA9481-0WJ40	-
3VA9211-0WK30	3VA9221-0WK30	3VA9481-0WK30	-
3VA9211-0WK40	3VA9221-0WK40	3VA9481-0WK40	-

# Connection technology

Configure your molded case circuit breaker easily online at www.siemens.com/lowvoltage/configurator-3VA

			3VA10	3VA11
Phase barriers (f	ixed mounting, plug-	in and draw-out units)		
44	Scope of supply			
	2 phase barriers		3VA9152	2-0WA00
DC insulation pla	ites for 3VA1 for fixed	d-mounted molded case circuit breakers		
	Number of poles			
20	3P		3VA911	3-0SG10
	4P		3VA911	4-0SG10
Side plates for 3	VA1 for fixed-mounte	ed molded case circuit breakers		
1	Number of poles	Mounting		
1 1	<b>2</b> P	On 2-pole molded case circuit breakers	3VA911	2-0SG20

	3VA20 3VA21	3VA13 3VA14 3VA23	3VA15
3VA12	3VA22	3VA24	3VA25
3VA9252-0WA00	3VA9262-0WA00	3VA9482-0WA00	3VA9602-0WA00
-	-	-	-
-	-	-	-
-	-	-	-

System overview, page 2/20 Siemens LV 10 · 10/2019 2/47

# Plug-in and draw-out technology

The main differences between plug-in units and draw-out units are convenience of operation and the potential for functional expansion.

#### Thanks to plug-in and draw-out technology:

- Molded case circuit breakers can be replaced quickly and easily for overhauls or servicing
- Electrical isolation and clearly visible isolating distance
- The socket can be interlocked to prevent the 3VA molded case circuit breaker from being plugged in or moved in
- Identical connection technology for all molded case circuit breakers, whether they are plug-in, draw-out or fixed-mounted units

#### In addition, draw-out technology offers:

- Transmission of the position of the molded case circuit breaker via communication (CONNECT, TEST, DISCONNECT)
- The ability to test the auxiliary and control circuit connections in the test position of the draw-out unit, without contacted main current paths
- Transmission of the state of the molded case circuit breaker (ON, OFF, TRIP) via the COM060 communication module

#### Configure your molded case circuit breaker easily online at

www.siemens.com/lowvoltage/configurator-3VA

					3VA13
				3VA20	3VA14
				3VA21	3VA23
			3VA12	3VA22	3VA24
Draw-out units	s, complete kits				
data .	<ul> <li>Scope of supply:         <ul> <li>Draw-out socket</li> <li>Conversion kit</li> <li>Mounting screw kit</li> </ul> </li> <li>Note: The crank handle for the draw-out unit must be ordered separately.</li> </ul>				
	Number of poles				
	3P	-	3VA9213-0KD00	3VA9123-0KD00	3VA9323-0KD00
	4P	-	3VA9214-0KD00	3VA9124-0KD00	3VA9324-0KD00
	s, conversion kits				
dad	<ul> <li>Scope of supply:         <ul> <li>Screw-fastened terminal covers for molded case circuit breakers</li> <li>Side panels</li> <li>Plug-in contacts</li> <li>Cable cages</li> <li>Autotrip plunger</li> </ul> </li> <li>Note: The crank handle for the draw-out unit must be ordered separately.</li> </ul>				
	Number of poles				
	3P	-	3VA9213-0KD10	3VA9123-0KD10	3VA9323-0KD10
	4P	-	3VA9214-0KD10	3VA9124-0KD10	3VA9324-0KD10
Plug-in units, c	complete kits				
	<ul> <li>Scope of supply:         <ul> <li>Plug-in base</li> <li>Conversion kit</li> <li>Mounting screw kit</li> </ul> </li> <li>Number of poles</li> </ul>				
ಡೆಡಡ	3P	3VA9113-0KP00	3VA9213-0KP00	3VA9123-0KP00	3VA9323-0KP00
	4P	3VA9113-0KP00 3VA9114-0KP00	3VA9213-0KP00 3VA9214-0KP00	3VA9123-0KP00 3VA9124-0KP00	3VA9323-0KP00 3VA9324-0KP00
Plug-in-units	conversion kits	3 V 7 3 1 1 4 - 0 V F 0 0	3VA32 14-0KF00	3VA3124-0KF00	3VA33Z4-0KF00
্যান্ত্ৰ-III dilits, c	Scope of supply:				
	<ul> <li>Screw-fastened terminal covers for molded case circuit breakers</li> <li>Plug-in contacts</li> <li>Cable cages</li> </ul>				
ववव	<ul> <li>Autotrip plunger</li> </ul>				
	Number of poles				
	3P	3VA9113-0KP10	3VA9213-0KP10	3VA9123-0KP10	3VA9323-0KP10
	4P	3VA9114-0KP10	3VA9214-0KP10	3VA9124-0KP10	3VA9324-0KP10

					3VA13
				3VA20	3VA14
				3VA21	3VA23
		3VA11	3VA12	3VA22	3VA24
Cable cages fo	r plug-in/draw-out units (spare part)				
itsiate anticipate	<ul> <li>Cable duct for routing of the required cables from the internal accessories on the back of the circuit breaker</li> </ul>				
	Number of poles				
	3P/4P	3VA9157-0KB02	3VA9257-0KB02	3VA9167-0KB02	3VA9367-0KB02
Door feedthro	ughs				
A					
		-	3VA9257-0KT00	3VA9167-0KT00	3VA9367-0KT00
Autotrip plung	ers (spare part)				
<b>A</b>	Version				
	Plug-in unit	3VA9157-0KP81	3VA9257-0KP81	3VA9267-0KP81	3VA9457-0KP81
	Draw-out unit	-	3VA9257-0KD81	3VA9267-0KD81	3VA9457-0KD81

#### Accessories

Accessories			
Communicatio	n links for draw-out unit		
İ	Scope of supply		Article No.
		special position signaling switches,	3VA9987-0KC00
	3VA9987-0KC10 connec	cting cables	
iti"			
Position signal	ng switches for draw-out (	ınit and plug-in unit	
4			Article No.
7			3VA9987-0KB00
Connecting cal			
	Purpose		Article No.
	Connection of position s	signaling switches for communication with COM060	3VA9987 <b>-</b> 0KC10
_			
rank handles	for draw-out units		
Talik Hallules	Version	Scope of supply	Article No.
	Insulated	Including crank handle holder	3VA9987-0KD81
Auxiliary circui	***************************************	Including crank nanuje nojder	3VA7707-0KD01
Auxiliary circui		connector is designed for 4 cables.	
-9	Version	connector is designed for it castes.	Article No.
L	For all draw-out units		3VA9987-0KD80
	For all plug-in units		3VA9987-0KP80
Cylinder locks	Tor all plug-in units		3VA9987-0KI 80
Lyllider locks	Scope of supply:		
	- 1 lock with 2 keys		
	For locking or interlo		
2 /	Note: Not for 3VA15		Australia Nila
	Key	Lock number	Article No.
	1	1	3VA9980-0VL10
	3	3	3VA9980-0VL30
	4	4	3VA9980-0VL40
ylinder lock a	dapters for draw-out units		
-40		zed withdrawal or insertion of the circuit breaker into the draw-out unit elocked in the CONNECT, TEST and DISCONNECT positions	
	Purpose	Procedure are contract, rest and discontract positions	Article No.
		k in the right-hand	
	side wall of the draw-ou		3V/19900 0E1 10
	For fitting a cylinder loc		3VA9980-0LF40

### Residual current devices RCD

According to IEC 60947-2 Annex B (Type A, Type B) and according to DIN VDE 0664-400 (Type B+)

Configure your molded case circuit breaker easily online at

www.siemens.com/lowvoltage/configurator-3VA

#### Mounted onto the side (left) · Can be mounted onto switch disconnectors and molded case circuit breakers Limit value of Rated voltage Num-Sensitivity<sup>3)</sup> Rated Fault Pre-alarm Tripped signal Type residual current ber of non-tripping U<sub>e</sub> poles response time frequency current I<sub>∆n</sub> Δt 3-pole RCD510 Type A 0.03 ... 5 A. 0 ... 3 s 127 ... 480 V AC 50/60 Hz 4-pole 0.03 ... 5 A. instantaneous 127 ... 480 V AC 50/60 Hz RCD310 Type A RCD510 0.03 ... 5 A. 127 ... 480 V AC 50/60 Hz Type A 0 ... 3 s

# Mounted below (under trip unit)

· Can be mounted onto molded case circuit breakers

Num- ber of	Туре	Sensitivity 3)	Rated residual	Limit value of non-tripping	Rated voltage	Fault current	Pre-	alarm		Tripp	ed signal	
poles			response current I <sub>Δn</sub>	time Δt	O <sub>e</sub>	frequency	÷	NC COM	COM	TRIP	NC COM	СОМ
3-pole	RCD520	Type A	0.03 5 A.	0 3 s	127 480 V AC	50/60 Hz	1	-	-			-
	RCD520B 1)4)	Type B	0.03 5 A.	0 10 s	127 690 V AC	0 100 kHz	1		-			-
	new	Type B+	0.03 0.3 A.									
	RCD820 <sup>2)</sup>	Type A	0.03 30 A <sup>5)</sup>	0 10 s	127 690 V AC	50/60 Hz	2					
4-pole	RCD320	Type A	0.03 5 A.	instantaneous	127 480 V AC	50/60 Hz	1	-	-			-
	RCD520	Type A	0.03 5 A.	0 3 s	127 480 V AC	50/60 Hz	1	-	-			-
	RCD520B4)	Type B	0.03 5 A.	0 10 s	127 690 V AC	0 100 kHz	1		-			-
•	new	Type B+	0.03 0.3 A.									
	RCD820 <sup>2)</sup>	Type A	0.03 30 A <sup>5)</sup>	0 10 s	127 690 V AC	50/60 Hz	2					

#### Residual current releases (spare part) new



Version For RCD310 or RCD510

Scope of supply RCR, RCR-RCD cables

- 3-pole version in 4-pole enclosure
- With energy infeed from below, the required auxiliary switch (AUX) must be ordered separately
- Type A: pulse current sensitive, type B/B+: universal current sensitive Sensitivity selectable for type B/B+
- If the molded case circuit breaker has no box terminals as connections, a set of box terminals must be ordered additionally for the taps below the thermal-magnetic trip units.

  7 1 set of box terminals is included in scope of supply of the RCD510 (3VA921.-ORS20).

Modular residual current devices type A/B (according to IEC 60947-2 Annex M) See monitoring devices, page 11/1

				3VA20						
Monitoring mode (tripping can be disabled as an option)	3VA24	3VA23	3VA22		RVA12	3VA11				
(tripping can be disabled as an option)         test/ remote reset         tion-capable remote reset           ■	JVAZT	37723	37722	JVAZI	JVAIZ	JVAII				
(tripping can be disabled as an option)         test/ remote reset         tion-capable remote reset           ■										
Nonitoring mode (tripping can be disabled as an option)								test/ remote	(tripping can be disabled as an	
Monitoring mode (tripping can be disabled as an option)	-	-	-	-	3VA9213-0RS20 <sup>7)</sup>	3VA9113-0RS20 <sup>6)</sup>	-	_	•	
Monitoring mode (tripping can be disabled as an option)         Remote test/ remote reset         Communication-capable           -         -         -         3VA9113-ORL20         3VA9213-ORL20         -	-	-	-	-	-	3VA9114-0RS10 <sup>6)</sup>	_	_		
(tripping can be disabled as an option)         test/ remote reset         tion-capable remote reset           -         -         -         3VA9113-0RL20         3VA9213-0RL20         -	-	-	-	-	3VA9214-0RS20 <sup>7)</sup>	3VA9114-0RS206)	-	-	•	
(tripping can be disabled as an option)         test/ remote reset         tion-capable remote reset           -         -         -         3VA9113-0RL20         3VA9213-0RL20         -										
(tripping can be disabled as an option)         test/ remote reset         tion-capable remote reset           -         -         -         3VA9113-0RL20         3VA9213-0RL20         -										
■ ■								test/ remote	(tripping can be disabled as an	
3VA9123-0RL30 3VA9223-0RL30 3VA9323-0RL30 3VA9 3VA9114-0RL10	-	_	-	_	3VA9213-0RL20	3VA9113-0RL20	_	-	-	
3VA9114-0RL10	-	-	-	-	-	3VA9113-0RL21	-	-	•	
3VA9114-0RL20 3VA9214-0RL20	0 3VA9423-0RL30	3VA9323-0RL30	3VA9223-0RL30	3VA9123-0RL30	-	-	•		•	
■	-	-	-	-	-	3VA9114-0RL10	-	-	-	
■	-	-	-	-	3VA9214-0RL20	3VA9114-0RL20	-	-	-	
	-	-	-	-	-	3VA9114-0RL21	-	-	•	
3VA9988-0BR10	0 3VA9424-0RL30	3VA9324-0RL30	3VA9224-0RL30	3VA9124-0RL30	-	-				
3VA9988-0BR10										
3VA9988-0BR10										
	-	-	-	-	3VA9988-0BR10	3VA9988-0BR10				

System overview, page 2/20 Siemens LV 10 · 10/2019 2/51

# Communication

Metering function <sup>1)</sup>			ETU 5- series	ETU 8- series	Display in ETU	Display DSP800	Communication COM800/COM100
Current							
Phase and neutral conductor currents	I <sub>1</sub> , I <sub>2</sub> , I <sub>3</sub> , I <sub>N</sub>	Α	-	-			
Residual current to ground	$I_g$	Α					-
Phase with highest load		Α	-				
Mean value over the three phase currents	$I_{leading axis} = (I_1 + I_2 + I_3)/3$	Α	-		-		
Asymmetry of the phase currents	I <sub>nba</sub>	%	-		-		-
THD of the 3 phases	THDI <sub>1</sub> , THDI <sub>2</sub> , THDI <sub>3</sub>	%	-		-		-
Voltage							
Phase voltages incl. mean value	$U_{12},  U_{23},  U_{31},  U_{phavg}$	V	-				
Voltages to N conductor incl. mean value	$U_{1N}$ , $U_{2N}$ , $U_{3N}$ , $U_{Navg}$	V	-		-		
Voltage unbalance		%	-		-		
THD phase/phase and phase/N	THDI <sub>1</sub> , THDI <sub>2</sub> , THDI <sub>3</sub>	%	-		-		
Power							
Active power, total and per phase	P <sub>1</sub> , P <sub>2</sub> , P <sub>3</sub> , P <sub>tot</sub>	kW	-		□ (P <sub>tot</sub> )		
Apparent power, total and per phase	S <sub>1</sub> , S <sub>2</sub> , S <sub>3</sub> , S <sub>tot</sub>	kVA	-		-		
Reactive power, total and per phase	Q <sub>1</sub> , Q <sub>2</sub> , Q <sub>3</sub> , Q <sub>tot</sub>	kVAr	-				
Power factor of the fundamental	P <sub>F1</sub> , P <sub>F2</sub> , P <sub>F3</sub> , P <sub>Favg</sub>		-		□ (PF <sub>avg</sub> )		
Energy							
Active energy, infeed and feedback	E <sub>p</sub>	kWh	-	•			
Reactive energy, infeed and feedback	Eq	kVArh	-		-		
Apparent energy	E <sub>s</sub>	kVAh	-		-		
Frequency							
Present frequency	f	Hz	-	-			
Maximum pointer function							
Min./max. current, voltage, power	With time stamp	-	-	-	-	-	


Depending on ETU version

■ Available

□ Displayable

– Not available

		3VA20 3VA21 3VA22	3VA23 3VA24 3VA25
COM060 commur			
	<ul> <li>For mounting in the right-hand accessories compartment of the 3VA2 molded case circuit breaker (including ETU power supply)</li> <li>Including a T-Connector</li> </ul>		
	Purpose		
	Communication to the COM800/COM100 breaker data server via 3VA line	3VA9187-0TB10	3VA9387-0TB10
24 V modules			
	<ul><li>24 V DC</li><li>For mounting in the right-hand accessories compartment of the 3VA2</li></ul>		
200	Purpose		
	Optional energy supply for the ETU, also includes continuous operation of the ETU display and the metering function of the ETU 8-series	3VA9187-0TB50	3VA9387-0TB50



 System overview, page 2/20
 Siemens LV 10 ⋅ 10/2019
 2/53

### Communication

#### Breaker data server

#### COM800 breaker data servers



Version

Central communication module for connection of up to eight 3VA2 molded case circuit breakers via the 3VA line, Ethernet 10/100 Mbps interface module socket for inserting an optional PROFIBUS DP or PROFINET module, 2 terminating resistors

Article No.
3VA9987-0TA10

#### COM100 breaker data servers



Version

Central communication module for connection of a 3VA2 molded case circuit breaker via the 3VA line,
Ethernet 10/100 Mbps interface module socket for inserting an optional PROFIBUS DP or PROFINET module,
2 terminating resistors

Article No. 3VA9987-0TA20

#### 7KM PAC PROFIBUS DP expansion modules



Purpose
Used for connecting the COM800/COM100 breaker data server, and the 3VA molded case circuit breakers connected to it, to PROFIBUS DPV1. Supplies the state and measured variables of the 3VA molded case circuit breaker for the PROFIBUS DP master. Receives information (e.g. commands) from the PROFIBUS DP master and transmits them to the 3VA molded case circuit breaker.

**Article No.** 7KM9300-0AB01-0AA0

#### 7KM PAC Switched Ethernet PROFINET expansion modules



Purpose
Used for connecting the COM800/COM100 breaker data server, and the connected 3VA molded case circuit breakers, to PROFINET via two Ethernet interfaces. Supplies the state and measured variables of the 3VA molded case circuit breakers to PROFINET via the PROFINET IO, PROFIenergy and Modbus TCP protocols.

Article No.
7KM9300-0AE01-0AA0

#### 7KM PAC RS485 Modbus RTU expansion modules



Used for connecting the COM800/COM100 breaker data server, and the 3VA molded case circuit breakers connected to it, to Modbus RTU. Supplies the state and measured variables of the 3VA molded case circuit breaker for the Modbus RTU master. Receives information (e.g. commands) from the Modbus RTU master and transmits them to the 3VA molded case circuit breaker.

7KM9300-0AM00-0AA0

Article No.

#### Interfaces to IEC 61850 new

The SICAM A8000 smart breaker data server connects the circuit breakers from the SENTRON portfolio
via the MODBUS TCP/IP protocol and transmits data via communication protocols (e.g.: IEC 61850,
IEC 60870-5-104, IEC 60870-5-101, MODBUS and DNP) to higher-level systems.





Processor assembly

Article No. 6MF28021AA00




SICAM PS-8620	-	24 60 V DC (12 W)	6MF28620AA00
SICAM PS-8622	_	110 220 V DC (12 W)	6MF28622AA00

**Operating voltage** 

You will find further information at: www.siemens.com/sicam-a8000

Designed for quantities of max. 20 devices, each with 50 data points



Siemens LV 10 · 10/2019 2/55

# Communication

#### **Accessories for communication**

The same of the sa	Purpose		Article No.
Lo	Provides a stub connection to the COM060 and loc	ons through to the next circuit breaker.	3VA9987-0TG10
ail adapter		po amenga, to the mont enemal process.	
All I	Purpose		Article No.
mi	For snapping the T-Connector onto a DIN rail.		3VA9987-0TG11
bricated co	onnecting cables, T-connector – T-connector or T-c	onnector – COM800/COM100	
	Length		Article No.
	0.4 m		3VA9987-0TC10
	1 m		3VA9987-0TC20
	2 m		3VA9987-0TC30
	4 m		3VA9987-0TC40
ricated co	onnecting cables for extending the COM060 – T-co	nnector stub connection	
	Length		Article No.
700	0.4 m		3VA9987-0TF20
700	0.8 m		3VA9987-0TF10
onal bus t	erminating resistors (spare part)		
17	Purpose		Article No.
	For COM800 and COM060		3VA9987-0TE10
ge tap for	external N conductors (spare part)		
1	Purpose		Article No.
	Cable for connection of the star point for the mete	ring function of the 8-series ETU, length 1.5 m	3VA9987-0UC10
nal curren	Cable for connection of the star point for the mete	ring function of the 8-series ETU, length 1.5 m	3VA9987-0UC10
nal curren		ring function of the 8-series ETU, length 1.5 m  Rated current I <sub>n</sub>	3VA9987-0UC10  Article No.
nal curren	t transformer for N conductors  Purpose  For 3VA2 3-pole molded case circuit breakers,		_
nal curren	t transformer for N conductors  Purpose  For 3VA2 3-pole molded case circuit breakers, for 5 and 8-series ETUs,	Rated current I <sub>n</sub>	Article No.
nal curren	t transformer for N conductors  Purpose  For 3VA2 3-pole molded case circuit breakers,	Rated current I <sub>n</sub> 25 150 A	Article No. 3VA9007-0NA10
}	t transformer for N conductors  Purpose  For 3VA2 3-pole molded case circuit breakers, for 5 and 8-series ETUs,	Rated current I <sub>n</sub> 25 150 A 160 350 A	Article No. 3VA9007-0NA10 3VA9107-0NA10
}	t transformer for N conductors  Purpose  For 3VA2 3-pole molded case circuit breakers, for 5 and 8-series ETUs, including connecting cables	Rated current I <sub>n</sub> 25 150 A 160 350 A	Article No. 3VA9007-0NA10 3VA9107-0NA10
}	t transformer for N conductors  Purpose  For 3VA2 3-pole molded case circuit breakers, for 5 and 8-series ETUs, including connecting cables  t transformers as straight-through transformers	Rated current I <sub>n</sub> 25 150 A 160 350 A	Article No. 3VA9007-0NA10 3VA9107-0NA10 3VA9307-0NA10
}	t transformer for N conductors  Purpose  For 3VA2 3-pole molded case circuit breakers, for 5 and 8-series ETUs, including connecting cables  t transformers as straight-through transformers  Rated current I <sub>n</sub>	Rated current I <sub>n</sub> 25 150 A 160 350 A	Article No. 3VA9007-0NA10 3VA9107-0NA10 3VA9307-0NA10 Article No.
}	t transformer for N conductors  Purpose  For 3VA2 3-pole molded case circuit breakers, for 5 and 8-series ETUs, including connecting cables  t transformers as straight-through transformers  Rated current I <sub>n</sub> 25 150 A	Rated current I <sub>n</sub> 25 150 A 160 350 A	Article No. 3VA9007-0NA10 3VA9107-0NA10 3VA9307-0NA10  Article No. 3VA9077-0NA10
}	t transformer for N conductors  Purpose  For 3VA2 3-pole molded case circuit breakers, for 5 and 8-series ETUs, including connecting cables  t transformers as straight-through transformers  Rated current I <sub>n</sub> 25 150 A  160 350 A	Rated current I <sub>n</sub> 25 150 A 160 350 A	Article No. 3VA9007-0NA10 3VA9107-0NA10 3VA9307-0NA10  Article No. 3VA9077-0NA10 3VA9177-0NA10
nal curren	t transformer for N conductors  Purpose  For 3VA2 3-pole molded case circuit breakers, for 5 and 8-series ETUs, including connecting cables  t transformers as straight-through transformers  Rated current I <sub>n</sub> 25 150 A  160 350 A  400 630 A	Rated current I <sub>n</sub> 25 150 A 160 350 A 400 630 A	Article No. 3VA9007-0NA10 3VA9107-0NA10 3VA9307-0NA10  Article No. 3VA9077-0NA10 3VA9177-0NA10 3VA9377-0NA10
nal curren	t transformer for N conductors  Purpose  For 3VA2 3-pole molded case circuit breakers, for 5 and 8-series ETUs, including connecting cables  t transformers as straight-through transformers  Rated current I <sub>n</sub> 25 150 A  160 350 A  400 630 A  600 1250 A	Rated current I <sub>n</sub> 25 150 A 160 350 A 400 630 A	Article No. 3VA9007-0NA10 3VA9107-0NA10 3VA9307-0NA10  Article No. 3VA9077-0NA10 3VA9177-0NA10 3VA9377-0NA10

#### Display

#### DSP800 displays



For displaying the status and measured values of up to eight devices

3VA2 via COM800/100

3VA27

- 3WL10
- 3WL11-13PAC3200T

System overview, page 2/20

Article No.

3VA9987-0TD10

#### **External function box**

#### EFB300 external function boxes



- 4 digital outputs for information output
- 1 digital input
- ZSI functionality
- S0-Interface
- Including cable 1.5 m in length

Purpose	Article No.
For connection to the ETU of 3VA2 molded case circuit breakers	3VA9987-0UA10


#### Connecting cables for EFB300



à	1 1 5500						
	Length	Purpose	Article No.				
	1.5 m	For 3VA2 with EFB	3VA9987-0UB10				
	3.0 m	For 3VA2 with EFB	3VA9987-0UB20				
		For 3VA2 with EFB and RCD820	3VA9987-0UB30				

#### **Test devices**

#### TD300 test devices Purpose Connection Article No. For activation of the ETU and initiation On the front interface of the ETU 3VA9987-0MA10 of a test tripping operation TD400 test devices • Energy supply via batteries or the USB-C interface USB-C interface for connecting a PC with powerconfig Bluetooth interface for connection to a PC, smartphone or tablet ETU parameterization Including adapter and connecting cable to 3VA2 molded case circuit breaker and IEC 3WL (ETU release 2) · Including case Purpose Connection Article No. Initiation of a test tripping operation On the front interface of the ETU (3VA and IEC 3WL ETU release 2) 3VW9011-0AT40 TD500 test devices • USB interface for connecting a PC with powerconfig · Including external power supply Including connecting cable to 3VA2 molded case circuit breaker Purpose Connection Article No. Initiation of various test tripping On the front interface of the ETU 3VA9987-0MB10 operations (LSING), ETU parameterization External power supplies for TD500 (spare part) Voltage Article No. 110 ... 240 V 3VA9987-0MX10 Connecting cables for connecting TD500 to 3VA2 molded case circuit breakers (spare part) Article No. 3VA9987-0MY10



# Locking, blocking and interlocking

						3VA20 3VA21
				3VA11	3VA12	3VA22
Locking	The locking devices make in either the OFF or the or		the 3VA molded case circuit breakers ion.			
	Version					
	Cylinder lock	Key 1 (lock num	ber 1)		3VA9980-0VL10	
		Key 3 (lock num	ber 3)		3VA9980-0VL30	
		Key 4 (lock num	ber 4)		3VA9980-0VL40	
	Adapter kit for mounting of the molded case circui		ee Ronis) in the accessories compartment	3VA9157-0LF10	3VA9257-0LF10	3VA9167-0LF10
	Locking device for toggle	operating mechanis	m	3VA908	8-0LB10	3VA9388-0LB10
Interlocking						
<u> </u>	<ul> <li>molded case circuit bre</li> <li>The interlock system is circuit breaker can be</li> </ul>	eakers. s designed to ensure operated at a time.	to mutually interlock two or more that no more than one molded case be used on 3VA molded case			
	Version					
	Cylinder lock	Key 1 (lock num	har 1)		3VA9980-0VL10	
	Cylinder lock	Key 3 (lock num			3VA9980-0VL10	
		Key 4 (lock num			3VA9980-0VL40	
	Sliding bar interlock			3VA9158-0VF30	3VA9258-0VF30	3VA9168-0VF30
	Module for handle interlo	ock using a Bowden c	able	3VA9157-0VF10	3VA9257-0VF10	3VA9167-0VF10
1	Bowden cable		Length 0.6 m		3VA9980-0VC10	
			Length 1.0 m		3VA9980-0VC20	
			Length 1.5 m		3VA9980-0VC30	
	Rear interlock with rod		Circuit breaker, fixed-mounted		3VA9088-0VM10	
il i			Plug-in/draw-out technology		3VA9088-0VM30	
	Mounting frame for rear	interlock with rod	Profile rails	3VA9088-0VK10	-	-
			Mounting panels	3VA9158-0VK20	3VA9258-0VK20	3VA9268-0VK20
1) Available from Q1/2020						

Available from Q1/2020
 With mounting frame for rear interlock.
 Can be used with breaker 3VA15 from "E02" and 3VA25 from "E05" (Line protection CB with TMTU, 3-Series ETU and 5-Series ETU)

214442							
3VA13 3VA14							
3VA23	3VA15						
3VA24	3VA25						
		Locking					
		<u> </u>					
		Use in	Locking in OFF position	Locking in ON position	Front mounting	Rear mounting	Interlocked breakers
3VA9980-0VL10	-	Breakers, motor-drive	•	•		-	-
3VA9980-0VL30	-	mechanisms, manual operators, withdraw-					
3VA9980 <b>-</b> 0VL40	_	able technology					
3VA9367-0LF10	3VA9587-0LF10	Circuit breaker	•	•	•	_	-
3VA9388-0LB10	3VA9588-0LB10	Circuit breaker	•	•	•	-	_
		Interlocking					
						D.	
		Use in	Locking in OFF position	Locking in ON position	Front mounting	Rear mounting	Interlocked breakers
3VA9980-0VL10	-	Breakers, manual	Locking in OFF position	Locking in ON position			
3VA9980-0VL30	-		OFF position	ON position	mounting		breakers
	= = =	Breakers, manual	OFF position	ON position	mounting		breakers
3VA9980-0VL30	-	Breakers, manual	OFF position	ON position	mounting		breakers
3VA9980-0VL30 3VA9980-0VL40	-	Breakers, manual operators	OFF position	ON position	mounting ■		<b>breakers</b> Unlimited
3VA9980-0VL30 3VA9980-0VL40	-	Breakers, manual operators	OFF position	ON position	mounting ■		<b>breakers</b> Unlimited
3VA9980-0VL30 3VA9980-0VL40	-	Breakers, manual operators	OFF position	ON position	mounting ■		<b>breakers</b> Unlimited
3VA9980-0VL30 3VA9980-0VL40 3VA9368-0VF30	- - -	Breakers, manual operators  Circuit breaker	OFF position	ON position	mounting		breakers Unlimited
3VA9980-0VL30 3VA9980-0VL40 3VA9368-0VF30	- - -	Breakers, manual operators  Circuit breaker	OFF position	ON position	mounting		breakers Unlimited
3VA9980-0VL30 3VA9980-0VL40 3VA9368-0VF30 3VA9367-0VF10	- - 3VA9587-0VF10 80-0VC10	Breakers, manual operators  Circuit breaker	OFF position	ON position	mounting		breakers Unlimited
3VA9980-0VL30 3VA9980-0VL40 3VA9368-0VF30 3VA9367-0VF10 3VA998	- - 3VA9587-0VF10 80-0VC10 80-0VC20	Breakers, manual operators  Circuit breaker	OFF position	ON position	mounting		breakers Unlimited
3VA9980-0VL30 3VA9980-0VL40 3VA9368-0VF30 3VA9367-0VF10 3VA998	- - 3VA9587-0VF10 80-0VC10	Breakers, manual operators  Circuit breaker	OFF position	ON position	mounting		breakers Unlimited
3VA9980-0VL30 3VA9980-0VL40 3VA9368-0VF30 3VA9367-0VF10 3VA998	- - 3VA9587-0VF10 80-0VC10 80-0VC20	Breakers, manual operators  Circuit breaker  Circuit breaker	OFF position	ON position	mounting		breakers Unlimited
3VA9980-0VL30 3VA9980-0VL40 3VA9368-0VF30 3VA9367-0VF10 3VA998 3VA998	- - 3VA9587-0VF10 80-0VC10 80-0VC20 80-0VC30	Breakers, manual operators  Circuit breaker  Circuit breaker  Circuit breaker	OFF position	ON position	mounting	mounting –	breakers Unlimited  3
3VA9980-0VL30 3VA9980-0VL40 3VA9368-0VF30 3VA9367-0VF10 3VA998 3VA998 3VA998 3VA998		Breakers, manual operators  Circuit breaker  Circuit breaker  Circuit breaker	OFF position	ON position	mounting	mounting –	breakers Unlimited  3
3VA9980-0VL30 3VA9980-0VL40 3VA9368-0VF30 3VA9367-0VF10 3VA998 3VA998 3VA998	3VA9587-0VF10  80-0VC10 80-0VC20 80-0VC30  3VA9588-0VM10 1) 2)	Breakers, manual operators  Circuit breaker  Circuit breaker  Circuit breaker	OFF position	ON position	mounting	mounting –	breakers Unlimited  3
3VA9980-0VL30 3VA9980-0VL40 3VA9368-0VF30 3VA9367-0VF10 3VA998 3VA998 3VA998 3VA998		Breakers, manual operators  Circuit breaker  Circuit breaker  Circuit breaker	OFF position	ON position	mounting	mounting –	breakers Unlimited  3
3VA9980-0VL40 3VA9980-0VL40 3VA9368-0VF30 3VA9367-0VF10 3VA998 3VA998 3VA998 3VA998		Breakers, manual operators  Circuit breaker  Circuit breaker  Circuit breaker	OFF position	ON position	mounting	mounting –	breakers Unlimited  3
3VA9980-0VL40 3VA9980-0VL40 3VA9368-0VF30 3VA9367-0VF10 3VA998 3VA998 3VA998 3VA998		Breakers, manual operators  Circuit breaker  Circuit breaker  Circuit breaker	OFF position	ON position	mounting	mounting –	breakers Unlimited  3

# Cover frame and mounting

- familia - manda - da	ad anna ainmid huandana	3VA11	
s for door cutouts for mold			
Number of poles 3P	Door cut-out with trip unit	3VA9053-0SB10	2)///02E2_0CB1
or or	No Yes		3VA9253-0SB10
40		3VA9053-0SB20	3VA9253-0SB20
4P	No	3VA9054-0SB10	3VA9254-0SB10
	Yes	3VA9054-0SB20	3VA9254-0SB20
s for MO320 motor operato	rs		
Purpose			
MO320 motor operat		3VA9053-0SB20	3VA9257-0SB3
Motor operator with	SEO520 stored energy operator	-	-
s for RCD320, RCD520 and	RCD820 residual current devices		
Number of poles			
3P		3VA9053-0SB10	3VA9253-0SB1
4P		3VA9054-0SB10	3VA9254-0SB1
s for front mounted rotary	operators		
		3VA9053-0SB10	3VA9253-0SB1
s for door feedthroughs		_	_
s for door feedthroughs		-	3VA9253-0SB2
s for door feedthroughs es for cover frame		-	3VA9253-0SB2
		- 3VA	3VA9253-0SB2 3VA9253-0SB2
es for cover frame  DIN rails for 3VA1 molded	case circuit breakers	- 3VA	_
es for cover frame  DIN rails for 3VA1 molded  Number of poles	case circuit breakers	_	_
es for cover frame  DIN rails for 3VA1 molded  Number of poles  1P	case circuit breakers	3VA9181-0SH10	_
s for cover frame  DIN rails for 3VA1 molded  Number of poles  1P  2P	case circuit breakers	3VA9181-0SH10 3VA9182-0SH10	_
s for cover frame  DIN rails for 3VA1 molded  Number of poles  1P  2P  3P and 4P		3VA9181-0SH10	_
DIN rails for 3VA1 molded  Number of poles  1P  2P  3P and 4P  3P and 4P in connect	case circuit breakers on with RCD310 or RCD510	3VA9181-0SH10 3VA9182-0SH10	_
DIN rails for 3VA1 molded  Number of poles  1P  2P  3P and 4P  3P and 4P in connect rew kits	on with RCD310 or RCD510	3VA9181-0SH10 3VA9182-0SH10 3VA9187-0SH10	_
DIN rails for 3VA1 molded Number of poles 1P 2P 3P and 4P 3P and 4P in connect rew kits Purpose	on with RCD310 or RCD510  Number of poles	3VA9181-0SH10 3VA9182-0SH10 3VA9187-0SH10 3VA9187-0SH20	A9087-05X10
DIN rails for 3VA1 molded  Number of poles  1P  2P  3P and 4P  3P and 4P in connect rew kits	on with RCD310 or RCD510  Number of poles eakers 1P	3VA9181-0SH10 3VA9182-0SH10 3VA9187-0SH10 3VA9187-0SH20 3VA9111-0SS10	A9087-05X10
DIN rails for 3VA1 molded Number of poles 1P 2P 3P and 4P 3P and 4P in connect rew kits Purpose	on with RCD310 or RCD510  Number of poles eakers 1P 2P and 3P (apart from 125 A/160 A with 55 kA and 70 kA)	3VA9181-0SH10 3VA9182-0SH10 3VA9187-0SH10 3VA9187-0SH20 3VA9111-0SS10 3VA9111	A9087-05X10  16-05S10
DIN rails for 3VA1 molded  Number of poles  1P  2P  3P and 4P  3P and 4P in connect rew kits  Purpose	on with RCD310 or RCD510  Number of poles eakers 1P 2P and 3P (apart from 125 A/160 A with 55 kA and 70 kA) 3P (125 A/160 A with 55 kA and 4P	3VA9181-0SH10 3VA9182-0SH10 3VA9187-0SH10 3VA9187-0SH20 3VA9111-0SS10 3VA9111	A9087-05X10  16-05S10
DIN rails for 3VA1 molded  Number of poles  1P  2P  3P and 4P  3P and 4P in connect rew kits  Purpose	on with RCD310 or RCD510  Number of poles eakers 1P 2P and 3P (apart from 125 A/160 A with 55 kA and 70 kA) 3P (125 A/160 A with 55 kA and 70 kA) and 4P 3P	3VA9181-0SH10 3VA9182-0SH10 3VA9187-0SH10 3VA9187-0SH20 3VA9111-0SS10 3VA9111	A9087-05X10  16-05S10 14-05S10
DIN rails for 3VA1 molded  Number of poles  1P  2P  3P and 4P  3P and 4P in connect ew kits  Purpose	on with RCD310 or RCD510  Number of poles eakers 1P 2P and 3P (apart from 125 A/160 A with 55 kA and 70 kA) 3P (125 A/160 A with 55 kA and 70 kA) and 4P 3P 4P	3VA9181-0SH10 3VA9182-0SH10 3VA9187-0SH10 3VA9187-0SH20 3VA9111-0SS10 3VA9111	A9087-05X10  16-05S10
DIN rails for 3VA1 molded  Number of poles  1P  2P  3P and 4P  3P and 4P in connect  ew kits  Purpose  For fixed-mounted br	on with RCD310 or RCD510  Number of poles eakers 1P 2P and 3P (apart from 125 A/160 A with 55 kA and 70 kA) 3P (125 A/160 A with 55 kA and 70 kA) and 4P 3P 4P 3P and 4P	3VA9181-0SH10 3VA9182-0SH10 3VA9187-0SH10 3VA9187-0SH20 3VA9111-0SS10 3VA911 	A9087-05X10
DIN rails for 3VA1 molded  Number of poles  1P  2P  3P and 4P  3P and 4P in connect  w kits  Purpose	on with RCD310 or RCD510  Number of poles eakers 1P 2P and 3P (apart from 125 A/160 A with 55 kA and 70 kA) 3P (125 A/160 A with 55 kA and 70 kA) and 4P 3P 4P 3P and 4P	3VA9181-0SH10 3VA9182-0SH10 3VA9187-0SH10 3VA9187-0SH20 3VA9111-0SS10 3VA911 	A9087-0SX10  16-0SS10 14-0SS10

	3VA13	
3VA20	3VA14	
3VA21	3VA23	3VA15
3VA22	3VA24	3VA25
3VA9163-0SB10	3VA9383-0SB10	3VA9503-0SB10
3VA9163-0SB20	3VA9363-0SB20	3VA9503-0SB20
3VA9164-0SB10	3VA9384-0SB10	3VA9504-0SB10
3VA9164-0SB20	3VA9364-0SB20	3VA9504-0SB20
3VA9257 <b>-</b> 0SB30	3VA9387-0SB30	
3VA9257-03B30 3VA9167-0SB30	3VA936/-03030	-
3VA9107-03B30	_	_
3VA9253-0SB10	3VA9303-0SB40	-
3VA9254-0SB10	3VA9303-03B40 3VA9304-0SB40	_
3779234-03610	31/7304-03040	_
3VA9163-0SB10	3VA9383-0SB10	3VA9503-0SB50
3VA9163-03B10	2AAA292-02810	2 A W A 2 O 2 - O 2 R 2 O
3VA9253-0SB20	3VA9353-0SB20	_
3749233-03620	3479333-03020	
	21/40007 05/10	
	3VA9087-0SX10	
-	-	-
_	-	-
_	-	-
-	-	-
-	-	-
-	-	-
-	-	-
3VA9126-0SS10	-	-
3VA9124-0SS10	-	-
-	3VA9328-0SS10	3VA9517-0SS10
-	-	-
3VA9124-0SS10	3VA9328-0SS10	-

System overview Page 2/20 Siemens LV 10 · 10/2019 2/61

# System overview

For a complete and verified configuration of your molded case circuit breaker, please use our online configurator at www.siemens.com/lowvoltage/configurator-3VA27

#### **Basic units**





Handle

Stored energy operator

#### Trip units





Electronic trip unit (ETU)

#### **Accessories**









Communication module

Rating plugs

**Breaker Connect** module

Test devices and breaker data adapters

#### Main conductor connections



horizontal



broadened



Front

extended



broadened



Cable lug

#### Accessories





**Motors** 

Rear



Spring charging motor

#### Accessories



Mechanical operating cycles counter (MOC)

### Auxiliary releases / closing coils





Undervoltage release (UVR) / Shunt release (ST)

Closing coil (CC) / Remote reset magnet (RR)

# Auxiliary switches







### Structure of the article numbers

Basic configuration with toggle operating mechanism  $\checkmark$ 

For a complete and verified configuration of your molded case circuit breaker, please use our online configurator at www.siemens.com/lowvoltage/configurator-3VA27






System overview, page 2/62 Siemens LV 10 · 10/2019 2/65

### Structure of the article numbers

#### Basic configuration with stored energy operating mechanism 9

For a complete and verified configuration of your molded case circuit breaker, please use our online configurator at www.siemens.com/lowvoltage/configurator-3VA27



	3VA	27	14	15				
Motor								
	Manual operator	0						
Operating mechanisms	Spring charging motor	24 30 V AC/DC 1			ı			
	Spring charging motor	48 60 V AC/DC 2			ı			
		110 V AC/DC 3						
		230 V AC/DC 4						
230 V ACIDC 4								
Auxiliary release	es, closing coils, remote res	et magnets						
Closing coil (CC),	Without		Α					
remote reset magnet (RR)	Closing coil (CC)	24 V AC/DC	В					
		30 V AC/DC	С					
		48 V AC/DC	D					
		60 V AC/DC	Е					
		110 120 V AC/DC	F					
		120 127 V AC/DC	G					
		220 240 V AC/DC	н					
		240 250 V AC/DC	J					
	Closing coil (CC) and	24 V AC/DC	K					
	additional remote reset magnet (RR)	110 V AC/DC	L					
		220 V AC/DC	M					
2nd auxiliary release	Without 2nd auxiliary release			А				
and duxinary release	With undervoltage release (UVR)	24 V AC/DC						
		30 V AC/DC		B C D E F G H				
		48 V AC/DC		D				
		60 V AC/DC		E				
		110 120 V AC/DC		F				
		120 127 V AC/DC		G				
		220 240 V AC/DC		Н				
		240 250 V AC/DC		J				
		380 400 V AC/DC		K				
		415 440 V AC/DC		K L M N				
	With undervoltage release (UVR),	24 30 V AC/DC		М				
	delayable with external time-delay device	110 127 V AC/DC		N				
	Scope of supply: UVR + time-delay device	220 250 V AC/DC		Р				
	With 2nd shunt release (ST2)	24 V AC/DC		Q				
		30 V AC/DC		R				
		48 V AC/DC		S				
		60 V AC/DC		S T				
		110 120 V AC/DC		U				
		120 127 V AC/DC		V				
		220 240 V AC/DC		W X				
		240 250 V AC/DC		Х				
1st auxiliary release	Without 1st auxiliary release							
	Shunt release (ST)	24 V AC/DC			-			
		30 V AC/DC			_			
		48 V AC/DC			1			
		60 V AC/DC			-			
		110 120 V AC/DC			-			
		120 127 V AC/DC			-			
		220 240 V AC/DC			-			
		240 250 V AC/DC			-			

# **Accessory options**

### Configure your molded case circuit breaker easily online at

www.siemens.com/lowvoltage/configurator-3VA27

To specify the options, add "-Z" to the complete Article No. and indicate the appropriate order code(s).

### 3VA27..-...-7

### Order code

S 5 6

ඉ ∡

5

#### Accessories for basic configuration

#### Mounting options for fixed mounting

• In the basic configuration, the fixed-mounted circuit breaker is mounted onto the rear panel. Floor mounting is possible as an option. The device must additionally be modified if it is to be extended to include functionalities such as external auxiliary switches or mechanical

Mounting options for
fixed mounting <sup>1)</sup>

	,			
Floor mounting	Mounting support standard	9	<u>∡</u>	
	Mounting support extended 2)	9	<u></u>	

Side wall extended 2)

#### Accessories for electronic trip units ETU

#### **Rating plugs**

- The electronic trip units are equipped as standard with a rating plug for setting the rated current I<sub>n</sub>, which is equal to the maximum rated circuit breaker current (<  $I_{n max}$ ). The rated current of the selected rating plug must be less than or equal to  $I_{n max}$
- To downrate the circuit breaker, a rated current smaller than I<sub>n max</sub> is selected for the rating plug via a Z option.
   Other functions can also be activated using rating plugs (L = OFF or Rc protection).

Rear panel mounting onto mounting plate

• Other functions can also be activated using fating plugs (L = OFF of Rc protection).								
Rating plug	For setting the rated current I <sub>n</sub>	For all ETU	400 A	9	∡	В	0	4
			630 A	9	∡	В	0	6
			800 A	9	∡	В	0	8
			1000 A	9	<u> </u>	В	1	0
	protection $L = OFF$ For setting the rated current $I_n$ , For For enabling the residual current protection function.		1200 A	9	<u> </u>	В	1	2
		For ETU 6-series	400 A	9	<u>∡</u>	L	0	4
			630 A	9	<u>∡</u>	L	0	6
			800 A	9	∡	L	0	8
			1000 A	9	∡	L	1	0
			1250 A	9	∡	L	1	2
			1600 A	9	∡	L	1	6
		For ETU660 only	400 A	9	<u> </u>	G	0	4
			630 A	9	<u>∡</u>	G	0	6
	The residual current function is only possible with the MF Advanced metering function.		800 A	9	∡	G	0	8
	Wit / Navariced metering randion.		1250 A	9	∡	G	1	2
Communication modules								

- When using an IOM040 digital I/O module (Z option K56), only 1 communication module can be used.

Communication modules	COM04
	COM04

COM043	Modbus TCP
COM042	Modbus RTU

#### **Breaker Connect modules**

- When a circuit breaker with a communications interface is ordered, a Breaker Connect module for external 24 V DC power supply of the electronic components is also supplied ready installed as standard.
- By means of this Z option, the Breaker Connect module for 24 V DC is replaced by a Breaker Connect module for 110-240 V AC/DC.

Breaker Connect module	110 240 V AC/DC	9	4	

i/O modules interna	11					
I/O modules internal	IOM040 digital I/O module	2 inputs, 2 outputs	9 4	K	5	6

- **9** For molded case circuit breakers with stored energy operating mechanism
- ✓ For molded case circuit breakers with toggle operating mechanism
- 1) These functionalities can be applied directly to the frame of the withdrawable circuit breaker,
- without any modification of the side wall.

  Not possible in connection with or as an alternative to the mounting support, standard (A07).

<u>⊿</u>

To specify the options, add "-Z" to the complete Article No. and indicate the appropriate order code(s).  3VA27Z						Z	Ord	der co	ode
Accessories for r	notors								
5-digit mechanical operating	cycles counter			9	_		С	0	1
5 argit meenamear operating	eyeles counter								Ĺ
Auxiliary switche	es and signaling swit	ches							
<ul> <li>Auxiliary and signaling swit</li> <li>For currents &lt;100 mA for Pl</li> </ul>	ches for currents >100 mA and up to 4 .C connections, these auxiliary and sig ches for 24 V DC digital signals are des nA at 5 V DC, and a	400 V AC are installed Inaling switches can b							
Position signaling switches f	or guide frames	2 CO   2 CO   2 CO (d	connected   test   disconnected position)	9	∡		К	5	5
Signaling switch	Ready-to-close signaling		1 CO contact digital 24 V DC	9	-		К	5	0
	Tripped signaling switch (S24)		1 CO contact digital 24 V DC	9	<u></u>		К	5	3
	Spring charged signaling switch (S2	1)	1 CO contact digital 24 V DC	9	-		К	5	4
Auxiliary switch	On / Off AUX	4 CO contacts digita	I 24 V DC	9	2		К	5	1
,,			AC, and 2 CO contacts digital 24 V DC		_		K	5	2
	g and interlocking								
Locking devices	To prevent movement of withdrawable circuit breaker	Cylinder lock	Made by Ronis	9	∡		R	7	8
	withdrawable circuit breaker	For no more than th	ree 8-mm padlocks	9	∡		R	6	5
Locking mechanism	To prevent movement to disconnect	ted position		9	∡		R	7	9
Locking device	To prevent unauthorized activation	Cylinder lock, made	by Ronis	9	-		s	0	8
	in the operator panel (safe OFF)	For no more than 3	padlocks, plastic 4 mm	9	-		S	2	2
		For no more than 1	padlock, metal 7 mm	9	-		S	2	3
		For no more than 2	padlocks, metal 8 mm	9	-		S	0	7
Padlockable protective	For mechanical ON and/or OFF on	For no more than 3	padlocks, plastic 4 mm	9	-		s	4	2
cover	the operator panel	For no more than 1	padlock, metal 7 mm	9	-		S	4	3
		For no more than 2	padlocks, metal 8 mm	9	-		S	4	4
Protective cover	For mechanical ON/OFF, not lockabl	le		9	-		s	4	1
Door sealing frame IP30	IP3x			9	<u> </u>		T	3	0
J									

 $<sup>\</sup>begin{tabular}{ll} \begin{tabular}{ll} \be$ 

### **Guide frames**

### Guide frames for ordering separately without circuit breakers

reakers

3VA27



- Guide frames without breakers up to 1250 A
- Note: All CB bus modules for communication COM04x / IOM300 / Breaker Connect module, as well as COMPSS signaling switches are configured without frames in the withdrawable circuit breaker and defined there by means of Z options, and are included with the switching device. PSS Standard is always included in the frame and can be changed to an electronics-capable signal by means of a Z option.

Number of poles	Connection type	Article No.
3-pole	Rear vertical	3VW8116-7AA01
	Rear horizontal	3VW8116-7AB01
	Front straight bus connectors extended	3VW8116-7AE01
	Broadened bus connectors	3VW8116-7AF01
<u></u>	Rear broadened bus connectors	3VW8116-7AG01
4-pole	Rear vertical	3VW8116-7BA01
	Rear horizontal	3VW8116-7BB01
	Front straight bus connectors extended	3VW8116-7BE01
	Broadened bus connectors	3VW8116-7BF01
	Rear broadened bus connectors	3VW8116-7BG01

To specify the options, add "-Z" to the complete Article No. and indicate the appropriate order code(s).  3VW8					-Z	Orc	ler co	ode
Locking, blocking and interlocking								
Locking device			9	∡		R	7	8
	withdrawable circuit breaker For no more than 3 8-mm padlocks		9	∡		R	6	5
Locking mechanism	To prevent movement to disco	nnected position (only in combination with R78 or R65)	9	∡		R	7	9
Auxiliary/signaling s	witches							
Position signaling switch PSS for guide frame	For 24 V DC digital signals, for minimum currents	2 CO   2 CO   2 CO (connected   test   disconnected position)	9	4		К	5	5

Auxiliary and signaling switches for currents >100 mA and up to 400 V AC are installed as standard. For currents <100 mA for PLC connections, these auxiliary and signaling switches can be modified. The auxiliary/signaling switches for 24 V DC digital signals are designed for

- a minimum load above 1 mA at 5 V DC, and
- a maximum breaking capacity of 100 mA at 24 V DC.

**<sup>9</sup>** For molded case circuit breakers with stored energy operating mechanism

# Electronic trip unit ETU and accessories

							3VA27
ectronic trip ur	nits (ETU)						
	Version	With communications / metering function, enhanced protection functions	Туре	Protective function			Article No.
	With rotary coding switches	No	ETU320	LIN	9	∡	3VW9011-5AA00
1 la p			ETU350	LSIN	9	<u>∠</u>	3VW9012-5AA00
•			ETU360	LSING	9	∡	3VW9012-7AA00
	With display	Yes	ETU650	LSIN	9	∡	3VW9017-5AA00
			ETU660	LSING	9	∡	3VW9017-7AA00
etering functio	ons for ETU650 or ETU660					-	
A A A	Description	Protective function / version		Arrangement			Article No.
0	Metering function	MF Basic		_	9	∡	3VW9011-0AT01
1		MF Advanced		_	9	<u>∡</u>	3VW9011-0AT04
	Set of cables for voltage tap for MF	For 4-pole circuit breakers with N conductor right		Top or bottom	9	∡	3VW9011-0AT08
	·	For 4-pole circuit breakers		Тор	9	∠	3VW9011-0AT75
		with N conductor left		Bottom	9	<u> </u>	3VW9011-0AT76
		For 3-pole circuit breakers		Тор	9	∠	3VW9011-0AT72
		•		Bottom	9	∡	3VW9011-0AT73
cternal current	transformers for N conductor	'S					
77.20	Accessory for	Purpose					Article No.
	ETU320, ETU350, ETU360, ETU650, ETU660	Only for 3-pole circuit breakers			9	<u>∡</u>	3VW9011-0AA30
cternal current	transformers for grounded tr	ansformer star points					_
	Accessory for	G <sub>ret</sub> (Ground return)					Article No.
	ETU660	100 A			9	∡	3VW9011-0GF30
		250 A			9	∡	3VW9011-0GF31
ımmation curre	ent transformers external Rc-	CT for residual current measurem	ent				_
	Only with MF Advanced m	etering function and Rc rating plug					
	Accessory for	Purpose					Article No.
	ETU660	For external residual current measurement			9	∡	3VW9011-0RC30
emote reset ma	agnets RR for the circuit break	ers including tripped signal					
	Remote reset magnet (RR)	for resetting the circuit breaker after	tripping as a res	ult of overcurren	t con	ditions	
	Accessory for	Voltage					Article No.
	ETU320, ETU350, ETU360,	24 V DC			9	-	3VW9011-0AK03
2	ETU650, ETU660	110 V AC/DC			9	-	3VW9011-0AK05
		250 V AC/DC			9	-	3VW9011-0AK06
eplacement bat	tteries for electronic trip unit	ETU					
	Accessory for						Article No.
	ETU320, ETU350, ETU360, E	TU650, ETU660			9	<u>∡</u>	3VW9011-0AT38

**<sup>9</sup>** For molded case circuit breakers with stored energy operating mechanism

# Electronic trip unit ETU and accessories

						3VA27
Rated current mod	dules / rating plugs					_
	Only one module	is possible per circuit breaker.				
In =400A	Accessory for Version Ra		Rated current I	l <sub>n</sub>	Article No.	
•	ETU320, ETU350,	Rating plugs for setting (< I <sub>n max</sub> )		400 A	<u> </u>	3VW9011-0AA53
	ETU360, ETU650,	the rated current I <sub>n</sub>		630 A	9 ∡	3VW9011-0AA55
	ETU660		8		9 ∡	3VW9011-0AA56
				1000 A	9 ∡	3VW9011-0AA57
		12		1250 A	<u> </u>	3VW9011-0AA58
				1600 A	9 👱	3VW9011-0AA61
	ETU 6-series	Rating plug without overload protection (L = 0	OFF)	400 A	9 ∡	3VW9011-0LF53
		and for setting ( $<$ $I_{n max}$ ) the rated current $I_{n}$		630 A	9 ∡	3VW9011-0LF55
				800 A	9 ∡	3VW9011-0LF56
				1000 A	9 ∡	3VW9011-0LF57
				1250 A	9 ∡	3VW9011-0LF58
				1600 A	<u> </u>	3VW9011-0LF61
	ETU660	Rating plug Rc for ETU660 for enabling the re-	sidual	400 A	9 ∡	3VW9011-0RC53
		current protection function and setting (< I <sub>n max</sub> ) the rated 630		630 A	9 ∡	3VW9011-0RC55
		current I <sub>n</sub> . The residual current function is onl	y possible	800 A	 9 <u>∡</u>	3VW9011-0RC56
		with the MF Advanced metering function.		1250 A	9 ∡	3VW9011-0RC58
	Can only be used breaker. This can	ital I/O module IOM040 (Z option K56), only 1 co with ETU of the 6-series and require a Breaker Co also be configured directly on the device by mea	nnect modu	le for connection	to the circuit	t
-		TU 6-series is selected.				
	Communication module	Protocol				Article No.
	COM043	Modbus TCP			9 ∡	3VW9011-0AT16
	COM042	Modbus RTU			9 ∡	3VW9011-0AT17
B bus modu <b>l</b> es - l	/O modules externa	I IOM300				
	For snapping onto	o standard mounting rail				
t in	Accessory for	Maximum switching current per contact	Inputs	Outputs		Article No.
	ETU 6-series	<ul> <li>2 A at ≤ 30 V DC</li> <li>0.8 A at 50 V DC</li> <li>0.2 A at 150 V DC</li> <li>4 A at 250 V AC</li> </ul>	11	10	9 <u>∡</u>	3VW9011-0AT20
B bus modules - I	/O modules internal	IOM040				
-	When using a dig	ital I/O module IOM040, only 1 communication r	nodule can b	e used.		
	Accessory for	Maximum switching current per contact	Inputs	Outputs		Article No.
RECEIPER	ETU 6-series	<ul> <li>2 A at ≤ 30 V DC</li> <li>0.8 A at 50 V DC</li> <li>0.2 A at 150 V DC</li> <li>4 A at 250 V AC</li> </ul>	2	2	9 <u>4</u>	3VW9011-0AT30

- $\ensuremath{ 9}$  For molded case circuit breakers with stored energy operating mechanism
- $\underline{\ensuremath{\angle}}$  For molded case circuit breakers with toggle operating mechanism

#### 3VA27 Actuator modules COM ACT For switching the circuit breaker on/off remotely via communication. Actuation of the closing coil (CC) and the 1st shunt release (ST). Can only be used in combination with a communication module, spring charging motor, closing coil and 1st shunt release. Automatically included if the communications interface of theETU 6-series is selected in the basic circuit breaker configuration. Accessory for Article No. ETU 6-series 9 -3VW9011-0AT10 **Breaker Connect modules** • For external power supply for the electronics components Article No. 110 ... 240 V AC/DC 3VW9011-0AT06 9 ∡ 24 ... 48 V DC 9 3VW9011-0AT07 Auxiliary contact signals for communications interfaces • Auxiliary contacts for signaling the readiness to close or for position signaling switches of the withdrawable positions. Can only be used in combination with communication module. Can be combined with standard position signaling switches or ready-to-close signaling contacts. Note: Both signaling switches are automatically included in the basic circuit breaker (COM PSS only with withdrawable versions) if the communications interface of the ETU 6-series is selected. Article No. 3VW9011-0AT11 Ready-to-close signaling switch for communication (COM RTC) 9 \_ Position signaling switch COM PSS (for withdrawable breaker only) 3VW9011-0AT12 9 ∡ Test devices and breaker data adapters • Usable for all ETU 3-series and 6-series Description Article No. Type TD310 Test device 9 ∡ 3VW9011-0AT32 For the trip test via ETU and tripping solenoid including release · Activation of the ETU and the tripping solenoid by means of a battery built into the test device On activation in the ETU 6-series, the parameters can be configured on the display Breaker data adapter 3VW9011-0AT34 TD410 As gateway for parameterization of the ETU with powerconfig • For generation of a report of the set parameters with powerservice Test device and breaker data adapter TD420 3VW9011-0AT33 · As gateway for parameterization of the ETU with powerconfig Testing a tripping operation using powerconfig · For use with the powerservice software Testing of the basic protection functions LSING Testing of the enhanced protection functions

**9** For molded case circuit breakers with stored energy operating mechanism

Test data storageReadout of ETU buffer

Generation of a report of the set parameters

∠ For molded case circuit breakers with toggle operating mechanism

## Accessories for connection and insulation

torminals	for main circuit conn	estions ass to IEC 60047.3			3VA27
terminais	<ul> <li>Acc. to IEC 6094</li> </ul>	ections acc. to IEC 60947-2 47-2 for 3VA27 up to 1600 A (dependi eparately for top and bottom	ng on application conditi	ons)	_
	Version	Description	Mounting onto	Number of poles / quantity	Article No.
	Fixed-mounted	Front terminals for main circuit	_	3-pole / 3 units 🧕 🗻	3VW9011-0AL01
19 00		connection		4-pole / 4 units <b>೨</b> ∠	3VW9011-0AL02
4		Extended main terminals,	Front terminals	3-pole / 3 units <b>೨</b> ∡	3VW9011-0AL77
		including insulation plate and phase barriers, standard	for main circuit connection	4-pole / 4 units <b>೨ ∠</b>	3VW9011-0AL78
		Broadened main terminals, including insulation plate and extended phase barriers	Front terminals for main circuit connection, top	3-pole / 3 units <b>೨ ∡</b>	3VW9011-0AL73
			Front terminals for main circuit connection, bottom	3-pole / 3 units <b>೨</b> ∡	3VW9011-0AL75
			Front terminals for main circuit connection, top/bottom	4-pole / 4 units <b>೨ </b> <u>✓</u>	3VW9011-0AL74
10 200	Withdrawable	Front-accessible terminals for	Guide frame flange	3-pole / 3 units <b>೨ ∠</b>	3VW9011-0AN01
		main circuit connection		4-pole / 4 units <b>9  ∠</b>	3VW9011-0AN02
		Broadened main circuit	Front-accessible	3-pole / 3 units <b>೨ ∠</b>	3VW9011-0AN73
50		connections	terminals for main circuit connection	4-pole / 4 units <b>9 ≼</b>	3VW9011-0AN74
		47-2 for 3VA27 up to 1600 A (dependi eparately for top and bottom	ng on application conditi	ons)	
	Fixing	Version	Mounting onto	Number of poles / quantity	Article No.
	Fixed-mounted	Rear terminals for main circuit connection, rotatable for horizontal / vertical connection including terminal cover	-	3-pole / 3 units	3VW9011-0AL32 3VW9011-0AL33
	Withdrawable	Rear terminals for main circuit	_	3-pole / 3 units <b>೨</b> <u>∠</u>	3VW9011-0AN32
71 44		connection, rotatable for horizontal / vertical connection Including terminal cover		4-pole / 4 units <b>೨</b> <u>∠</u>	3VW9011-0AN33
		Broadened main terminals	Rear horizontal main	3-pole / 3 units <b>೨</b> <u>⊀</u>	3VW9011-0AN75
1			connections	4-pole / 4 units <b>೨</b> <u>∠</u>	3VW9011-0AN76
I cable con	nections acc. to IEC 6	0947-2	connections	4-pole / 4 units 9 🚄	3VW9011-0AN76
I cable con		5 <mark>0947-2</mark> 17-2 for 3VA27 up to 1600 A (dependi eparately for top and bottom			3VW9011-0AN76
I cable con	<ul> <li>Acc. to IEC 6094</li> </ul>	17-2 for 3VA27 up to 1600 A (dependi			3VW9011-0AN76
I cable con	<ul><li>Acc. to IEC 6094</li><li>To be ordered se</li></ul>	47-2 for 3VA27 up to 1600 A (dependi eparately for top and bottom Version Circular conductor terminals	ng on application conditi	ons)	3VW9011-0AN76  Article No. 3VW9011-0AL71
I cable con	<ul><li>Acc. to IEC 6094</li><li>To be ordered se</li><li>Fixing</li></ul>	47-2 for 3VA27 up to 1600 A (dependi eparately for top and bottom <b>Version</b>	ng on application conditi	ons)  Number of poles / quantity	Article No.
I cable con	<ul><li>Acc. to IEC 6094</li><li>To be ordered se</li><li>Fixing</li></ul>	47-2 for 3VA27 up to 1600 A (dependi eparately for top and bottom Version Circular conductor terminals 4 x 240 mm <sup>2</sup> for front cable connection, including insulation plate and high,	ng on application conditi  Mounting onto  Front terminals for main circuit	ons)  Number of poles / quantity  3-pole / 3 units 9 4	Article No. 3VW9011-0AL71

**<sup>9</sup>** For molded case circuit breakers with stored energy operating mechanism

 $<sup>\</sup>underline{\ensuremath{\angle}}$  For molded case circuit breakers with toggle operating mechanism

#### 3VA27 Auxiliary supply connectors in push-in version · Auxiliary conductor terminal in push-in version for upgrading fixed-mounted breakers and guide frames. • The device is always fitted at the factory with the exact number of auxiliary conductor terminals required. Version Article No. Push-in 9 ∡ 3VW9011-0AB11 Terminal covers for fixed circuit breakers Finger-proof for front terminals for main circuit connection for fixed-mounting Necessary isolation measures are always supplied with the corresponding connection technology and do not need to be ordered separately. Version Number of poles / quantity Article No. Standard 3-pole / 2 units 9 ∡ 3VW9723-0WD30 4-pole / 2 units 9 ∡ 3VW9724-0WD40 Extended 3-pole / 2 units 3VW9723-0WF30 9 ∡ 4-pole / 2 units 3VW9724-0WF40 9 ∡ Phase barriers for fixed breakers · Necessary isolation measures are always supplied with the corresponding connection technology and do not need to be ordered separately • For operating voltages >440 V AC the use of phase barriers is mandatory; up to 440 V AC their use is optional. Height Number of poles / quantity Article No. 100 mm (standard) 3-pole / 4 units 9 ∡ 3VW9723-0WA00 4-pole / 6 units <u> ∡</u> 3VW9724-0WA10 9 ∡ 3VW9723-0WA01 200 mm (extended) 3-pole / 4 units 3VW9724-0WA11 4-pole / 6 units 9 ∡ Supports for mounting the fixed-mounted breakers on the floor · For fixed-mounted versions only Version Article No. Purpose Mounting support standard 9 4 3VW9011-0BB51 (circuit breaker feet) (= Z option A07) Mounting support extended • Fixation for external auxiliary switches AUX 15 CO 3VW9011-0BB52 (3VW9011-0AG15) (circuit breaker feet) Locking mechanism for control cabinet door, direct including mechanical trans-(for 3VW9011-0BB10) mission of switch position Locking mechanism for control cabinet door, Bowden cable on circuit breaker side panel \* (for 3VW9011-0BB16), (= Z option S56) • Mutual mechanical interlocking to 3WL/3VA (for 3VW9011-0BB21) Extension kits for modification of the side wall of the fixed-mounted breakers · For fixed-mounted breakers only · Rear fixation on mounting plate • For modification for mechanical transmission of switch position on circuit breaker side panel (= Z option S57) Version Article No. 3VW9011-0BB53 Extension kit for side wall • Fixation for external auxiliary switches AUX 15 CO 9 4 (3VW9011-0AG15) Locking mechanism for control cabinet door, direct (for 3VW9011-0BB10) Locking mechanism for control cabinet door, Bowden cable (for 3VW9011-0BB16). • Mutual mechanical interlocking to 3WL/3VA (for 3VW9011-0BB21)

- **9** For molded case circuit breakers with stored energy operating mechanism
- ∠ For molded case circuit breakers with toggle operating mechanism

# Motor operators and manual operators

					3VA27
Spring charging m	otor (MO)				
F 100	Description		Version		Article No.
	For automatic charging of t	he stored energy operating	24 30 V AC/DC	9 –	3VW9011-0AF01
	mechanism		48 60 V AC/DC	9 -	3VW9011-0AF02
			100 130 V AC/DC	9 –	3VW9011-0AF03
			220 250 V AC/DC	9 –	3VW9011-0AF04
Mechanical operat	ting cycles counter MOC				
	Description		Version		Article No.
00000	Only possible in combination motor.	on with a spring charging	5 digits	<b>9</b> –	3VW9011-0AH07
Manual operators	for circuit breakers with to	ggle operating mechanism	n		
	Description	Version	Color		Article No.
	Front rotary operating	Standard	Gray	- <u>∡</u>	3VW9727-0EK11
	mechanism incl. door sealing frame	EMERGENCY STOP	Yellow-red	- ≰	3VW9727-0EK15
	Door mounted rotary	Standard	Gray	- <u>∡</u>	3VW9727-0FK21
	operator	EMERGENCY STOP	Yellow-red	- ∡	3VW9727-0FK25
		Basic without handle		- ≰	3VW9727-0GK00
		Shaft stub		- ≰	8UD1900-3WD00
		Handle	Gray	- <u>∡</u>	8UD1861-0AB11
			Yellow-red	- ∡	8UD1861-0AB15

**<sup>9</sup>** For molded case circuit breakers with stored energy operating mechanism

 $<sup>\</sup>underline{\ensuremath{\angle}}$  For molded case circuit breakers with toggle operating mechanism

## Auxiliary release, closing coil

#### 3VA27 Closing coils / shunt releases CC / ST 24 V AC/DC 3VW9011-0AD01 30 V AC/DC 3VW9011-0AD02 48 V AC/DC 3VW9011-0AD03 60 V AC/DC 3VW9011-0AD04 110 ... 120 V AC/DC 3VW9011-0AD05 120 ... 127 V AC/DC 3VW9011-0AD06 220 ... 240 V AC/DC 3VW9011-0AD07 240 ... 250 V AC/DC 3VW9011-0AD08 380 ... 400 V AC 3VW9011-0AD17 415 ... 440 V AC 3VW9011-0AD18 TD320 function test units for closing coils / shunt releases • The TD320 test unit allows the operational availability and functions of the closing coils and shunt releases with a rated operational voltage between 24 V and 250 V (AC and DC) to be tested. The operational availability test is performed cyclically at intervals of 30 seconds. The unit has visual indicators in the form of LEDs on the front in order to display the following states: LED POWER ON LIT: Correct function of the YO/YC test unit LED DEACTIVATION LIT: Power supply failure, wire break LED SHORT-CIRCUIT LIT: Winding short-circuit LED DEACTIVATION and SHORT-CIRCUIT FLASHING: Incorrect power supply LED DEACTIVATION and SHORT-CIRCUIT OFF: Closing coil / shunt release OK Article No. For all closing coils / shunt releases 9 3VW9011-0AT31 Auxiliary / signaling switches • The auxiliary/signaling switches for 24 V DC digital signals are designed for a - minimum load above 1 mA at 5 V DC, and a maximum breaking capacity of 100 mA at 24 V DC. For external auxiliary switches ON/OFF AUX 15 CO, a 3VW9011-0AG1x fixation must be ordered in addition, and for fixed-mounted breakers a 3VW9011-0BB5x side wall modification. Description Article No. Version Ready-to-close signal RTC 1 CO standard 3VW9011-0AH01 1 CO digital 3VW9011-0AH02 Auxiliary switch ON/OFF AUX 4 CO standard 3VW9011-0AG01 4 CO digital 3VW9011-0AG02 2 CO standard + 2 CO digital 3VW9011-0AG03 External auxiliary switch ON/OFF AUX 3VW9011-0AG05 15 CO standard 15 CO digital 3VW9011-0AG06 Tripped signaling switch S24 1 CO standard 3VW9011-0AH14 1 CO digital 3VW9011-0AH15 Spring charged signaling switch S21 1 CO standard 3VW9011-0AH10 1 CO digital **9** \_ 3VW9011-0AH08 Position signaling switches PSS 2 CO | 2 CO | 2 CO 3VW9011-0AH11 9 4 (only with draw-out versions) (connected | test | disconnected position) standard 2 CO | 2 CO | 2 CO 9 4 3VW9011-0AH12

(connected | test | disconnected position) digital

- **9** For molded case circuit breakers with stored energy operating mechanism

# Auxiliary release, closing coil

### Auxiliary / signaling switches for toggle operating mechanisms

- Auxiliary and signaling switches are each offered in two versions:
  - Standard version for currents >100 mA and up to 400/250 V AC,
  - Minimum load above 100 mA at 24 V DC
  - Maximum breaking capacity 5 A at 250 V AC
  - Digital version for currents <100 mA for PLC connections, minimum load above 1 mA at 5 V DC, and maximum breaking capacity of 100 mA at 24 V DC
- For external auxiliary switches ON/OFF AUX 15 CO, a 3VW9011-0AG1x fixation must be ordered in addition, and for fixed-mounted breakers a 3VW9011-0BB5x side wall modification.

Description	Version		Article No.
Trip alarm switch TAS signals the trip position	1 CO standard	- 4	3VW9727-0AB11
irrespective of the tripping reason	1 CO digital	- 4	3VW9727-0AB13
Tripped signaling switch via auxiliary release S25 signals	1 CO standard	- <u>-</u>	3VW9727-0AB41
tripping operations via auxiliary releases (UVR, ST) in UVR/ST2 pocket	1 CO digital	- <u>-</u>	3VW9727-0AB43
Leading auxiliary switch S26 (2 units)	1 NO standard, 250 V AC	- <u>-</u>	3VW9727-0AA21

### Fixation for external auxiliary switches AUX 15 CO



External auxiliary switches ON/OFF AUX 15 CO must be ordered separately.
 Version Article No.
 For fixed-mounted breakers with rear panel or floor mounting (in combination with Z option S56 or S57)
 For guide frames 9 ∠ 3VW9011-0AG17

### Undervoltage releases UVR



ses UVR		
Version		Article No.
24 V AC/DC	9 ∡	3VW9011-0AE01
30 V AC/DC	9 <u>∡</u>	3VW9011-0AE02
48 V AC/DC	9 <u>∡</u>	3VW9011-0AE03
60 V AC/DC	9 <u>∡</u>	3VW9011-0AE04
110 120 V AC/DC	9 ∡	3VW9011-0AE05
120 127 V AC/DC	9 <u>∡</u>	3VW9011-0AE06
220 240 V AC/DC	9 ∡	3VW9011-0AE07
240 250 V AC/DC	9 ∡	3VW9011-0AE08
380 400 V AC	9 ∡	3VW9011-0AE17
415 440 V AC	9 <u>∡</u>	3VW9011-0AE18

### External time-delay devices for undervoltage releases



- With adjustable delay time from 0.5 to 3 s.
- Suitable for mounting onto DIN rail.

Version		Article No.
24 30 V AC/DC	9 <u></u>	3VW9011-0AE10
48 V AC/DC	9 <u>4</u>	3VW9011-0AE11
60 V AC/DC	9 <u></u>	3VW9011-0AE15
110 127 V AC/DC	9 <u></u>	3VW9011-0AE12
220 250 V AC/DC	9 <u>∡</u>	3VW9011-0AE13

3VA27

**<sup>9</sup>** For molded case circuit breakers with stored energy operating mechanism

# Interlocking

				3VA27
cking devices t	to prevent movement of the withdrawab	le circuit breakers		
	Version			Article No.
	Ronis cylinder lock (replacement for R78)		9 ∡	3VW9011-0BA80
	Padlock 8 mm (replacement for R65), for	no more than 3 padlocks	9 <u>4</u>	3VW9011-0BA87
cking mechani	isms to prevent movement of the withdr	awable circuit breakers in disconnected po	sition	
		nction with R78 (3VW9011-0BA80) and/or R65 (	3VW9011-0BA87).	
	Description			Article No.
	Locking mechanism (replacement for R79	)	<u>9</u> <u>4</u>	3VW9011-0BA84
cking devices i	in OFF position			
	<ul> <li>For fixed-mounted versions and withdr</li> <li>To prevent unauthorized activation in t</li> <li>The disconnector unit fulfills the condit</li> </ul>		e acc. to EN 60204-1.	
	Description			Article No.
	Cylinder lock, made by Ronis (replacemen	t for S08)	9 -	3VW9011-0BA33
king devices i	in OFF position			
	<ul><li>For fixed-mounted versions and withdr</li><li>To prevent unauthorized activation in t</li></ul>			
	Description	Version		Article No.
	Padlock 4 mm (replacement for S22)	Plastic for no more than 3 locks	9 -	3VW9011-0BA41
	Padlock 7 mm (replacement for S23)	Metal for no more than 1 lock	9 -	3VW9011-0BA42
	Padlock 8 mm (replacement for S07)	Metal for no more than 2 locks	9 –	3VW9011-0BA44
cking devices i	n OFF position for toggle operating mec	hanisms with rotary operators		
	To prevent unauthorized activation in t	he case of molded case circuit breakers with rota	ary operator	
	Description			Article No.
	For Ronis		- ∡	3VW9727-0VL10
cking devices i	in OFF position for toggle operating mec	hanisms without rotary operators		
	To prevent unauthorized activation in t molded case circuit breakers without ro			
	Description	orang operator		Article No.
	For padlocks		- 🚣	3VW9727-0LB10
	For Ronis		- 4	3VW9727-0LF10
dlockable prot	ective covers ON/OFF on the operator pa	nels		
	Description	Version		Article No.
THE RESERVE TO SERVE THE PARTY OF THE PARTY				21/14/0011 00422
HICH	Padlock 4 mm (replacement for S42)	Plastic for no more than 3 locks	9 –	3VW9011-0BA22
	Padlock 4 mm (replacement for S42) Padlock 7 mm (replacement for S43)	Plastic for no more than 3 locks  Metal for no more than 1 lock	9 -	3VW9011-0BA22 3VW9011-0BA23

- ${\color{red} {\bf 9}} \ \, {\rm For molded \ case \ circuit \ breakers \ with \ stored \ energy \ operating \ mechanism}$
- ∠ For molded case circuit breakers with toggle operating mechanism

# Interlocking

Protective covers	s for mechanical ON/OFF				3VA27
Totective covers		protect against unintention	nal actuation on the operator panel.		
	Description				Article No.
	Not lockable (replaceme	nt for S41)		9 –	3VW9011-0BA21
Mutual mechani	cal interlocking				
80	<ul> <li>Mutual mechanical in</li> </ul>	terlocking with Bowden cab	le 2 m		
	Fixing	Mounting			Article No.
是机	Fixed-mounted	Rear panel or floor mo	ounting	9 👱	3VW9011-0BB21
	Withdrawable	Mounting onto guide	frame	9 <u></u>	3VW9011-0BB22
Bowden cables,	separate				
	One required for each	circuit breaker			
	Variant				Article No.
	1000 mm				3VW9011-0BB23
	2000 mm				3WL9111-0BB45-0AA0
	3000 mm				3WL9111-0BB46-0AA0
Locking mechani	isms to prevent opening o	of the control cabinet do	ors in ON position		
· Marine		f the control cabinet door in s the circuit breaker from be	ON position eing closed when the control cabinet door	is open.	
1	Fixing		Version		Article No.
	Fixed mounting on side	panel or floor	Direct fixed interlocking	9 ∡	3VW9011-0BB10
= 0			Locking with Bowden cable	<u> </u>	3VW9011-0BB16
4	Withdrawable		Direct fixed interlocking	9 <u>∡</u>	3VW9011-0BB14
Ä			Locking with Bowden cable	9 <u>∡</u>	3VW9011-0BB18
Door sealing fran	nes IP30				
	<ul> <li>For IP4x and higher, y</li> </ul>	ou must order the protectiv	e cover IP54 3VW9011-0AP03 or 3VW901	I-0AP13.	
	Description	Fixing	Version		Article No.
	Replacement part	Fixed-mounted	IP3x	<u> </u>	3VW9011-0AP01
	for Z option T30.	Withdrawable	IP3x	9 –	3VW9011-0AP02
				- 📥	3VW9011-0AP04
Protective covers	s IP54				
	<ul> <li>For implementing deg</li> </ul>	rees of protection IP4x and	unted breakers and withdrawable breaker IP54 when installing in switchboard door. e and door mounted rotary operator.	s	
1	Description		Version		Article No.
-	Lock with unique key		IP54	9 ∡	3VW9011-0AP03
	Lock with standard key		IP54	9 ∡	3VW9011-0AP13

- **9** For molded case circuit breakers with stored energy operating mechanism
- $\underline{\hspace{0.1cm} \angle\hspace{0.1cm}}$  For molded case circuit breakers with toggle operating mechanism

## 3VL up to 1600 A, IEC



3VL molded case circuit breaker



### **Product Discontinuation**

The 3VL molded case circuit breaker up to 1600 A IEC will only be able to be ordered as a spare part from 10/2020, and will be removed from the order portfolio from 10/2025.

### Documents available for downloading:

You can find comprehensive information on the 3VL molded case circuit breaker in the catalog excerpt.

3VL molded case circuit breaker (109769073)

## Conditions of sale and delivery

### 1. General standards

By using this catalog you can acquire hardware and software products described therein from Siemens AG subject to these conditions of sale and delivery (hereinafter: CSD). Please note! The scope, the quality and the conditions for supplies and services, including software products, by any Siemens entity having a registered office outside Germany, shall be subject exclusively to the General Terms and Conditions of the respective Siemens entity. These CSD apply exclusively for orders placed with Siemens AG, Germany.

### 1.1 For customers with a seat or registered office in Germany

For customers with a seat or registered office in Germany, the following shall be subordinate to these CSD

- for installation, the "Standard Terms and Conditions for Installation Germany" and
- for Plant Analytics Services the "Standard Terms and Conditions for Plant Analytics Services for Customers in Germany" 1) and
- for standalone software products and software products that are part of another product or project, the "General License Conditions for Software Products for Automation and Drives for Customers with a Seat or Registered Office in Germany" 1) and
- for other supplies and services, the "General Conditions for the Supply of Products and Services of the Electrical and Electronics Industry" 1).
  - In the event that such other supplies and services include open-source software, the conditions of which override the "General Conditions for the Supply of Products and Services of the Electrical and Electronics Industry" 1), the product will be supplied with a notice detailing the special conditions that apply for the relevant open-source software. This applies accordingly in the case of a reference to other third-party software components.

### 1.2 For customers with a seat or registered office outside of Germany

For customers with a seat or registered office outside of Germany, the following shall be subordinate to these CSD

- for Plant Analytics Services the "Standard Terms and Conditions for Plant Analytics Services" <sup>1)</sup> (only available in English) and
- for services, the "International Terms & Conditions for Services" 1) supplemented by the "Software Licensing Conditions" 1) and
- for the supply of other hardware and software the "International Terms & Conditions for Products" 1) supplemented by the "Software Licensing Conditions" 1).

### 1.3 For customers with framework agreements

To the extent that our products and services are covered by an existing framework agreement, the conditions there apply instead of this CSD.

### 2. Additional terms and conditions

All dimensions are in mm. In Germany, according to the German law on units in metrology, data in inches only apply to devices for export.

Illustrations are not binding.

Insofar as there are no remarks on the corresponding pages of this catalog – especially with regard to data, dimensions and weights given – these are subject to change without prior notice.

### 3. Export regulations

We shall not be obligated to fulfill this agreement if such fulfillment is prevented by any impediments arising out of national or international foreign trade or customs requirements or any embargoes or other sanctions.

Exporting may be subject to authorization. In delivery information, we label authorization obligations according to German, European and US export lists.

Our products are controlled by the U.S. authorities (goods labeled with "ECCN" not equal to "N") and may only be supplied to the stated country of the end user for sole use by the end user. Without U.S. government approval or other approval under U.S. law, the products may not be sold, transferred or otherwise forwarded to other countries or to other persons other than the specified end user, either in their original form or after further processing into other goods. Goods labeled with an "AL" not equal to "N" are subject to European/national export authorization requirements.

Please note that you can also preview the export designations in the respective product description via our "Industry Mall" online catalog system. The deciding factors, however, are the AL or ECCN export designations indicated on order confirmations, delivery notes and invoices.

Unmarked items or items marked "AL:N" / "ECCN:N" or "AL:9X9999" / "ECCN: 9X9999" may require authorization based on their intended use or ultimate destination.

If you transfer goods (hardware and/or software and/or technology as well as corresponding documentation, regardless of the mode of provision) delivered by us or works and services (including all kinds of technical support) performed by us to a third party worldwide, you shall comply with all applicable national and international (re-)export control regulations.

¹) You can download the text of the Siemens AG terms and conditions of trade at www.siemens.com/automation/salesmaterial-as/catalog/en/terms\_of\_trade\_en.pdf

Α

If required to conduct export control checks, you, at our request, shall promptly provide us with all information pertaining to particular end customers, destination and intended use of goods, works and services provided by us, as well as any relevant export control restrictions.

The products listed in this catalog may be subject to European/German and/or US export regulations. Therefore, any export requiring a license is subject to approval by the competent authorities.

Errors excepted and subject to change without prior notice.

# Link directory

### Catalog LV 10

### **General information**

Information on low-voltage power distribution and electrical installation technology	www.siemens.com/lowvoltage
Tender specifications	www.siemens.com/lowvoltage/tenderspecifications
Conversion tool	www.siemens.com/conversion-tool
Image database	www.siemens.com/lowvoltage/picturedb
CAx download manager	www.siemens.com/lowvoltage/cax
Newsletter system	www.siemens.com/lowvoltage/newsletter
Siemens YouTube channel	www.youtube.com/Siemens
Brochures / catalogs	www.siemens.com/lowvoltage/catalogs
Operating instructions / manuals	www.siemens.com/lowvoltage/manuals
Siemens Industry Online Support	www.siemens.com/lowvoltage/product-support
Siemens Industry Online Support app	www.siemens.com/support-app
My Documentation Manager (MDM)	www.siemens.com/lowvoltage/mdm
Configurators	www.siemens.com/lowvoltage/configurators
Siemens Industry Mall – product catalog and	www.siemens.com/industrymall
online ordering system	
Direct forwarding to the Industry Mall	www.siemens.com/product? <u>Article No.</u>
Interactive product catalog CA 01	www.siemens.com/automation/ca01
Training	www.siemens.com/sitrain-lowvoltage
Local contacts	www.siemens.com/lowvoltage/contact
Technical Support	www.siemens.com/lowvoltage/support-request
Information on services	www.siemens.com/service-catalog
Application consulting for control panel construction,	www.siemens.com/applicationconsulting
machine manufacture, and plant building	
Manual for the generation, transmission and distribution of electrical energy	www.siemens.com/power-engineering-guide
Control panels for the North American market	www.siemens.com/northamerican-standards
Control panel building	www.siemens.com/controlpanel
Energy savings and amortization	www.automation.siemens.com/sinasave
Energy Suite	www.siemens.com/energysuite
SITOP power supplies	www.siemens.com/sitop
Efficiency class IE3	www.siemens.com/IE3ready
Power distribution with Totally Integrated Power	www.siemens.com/tip
rower distribution with rotally integrated rower	www.siemens.com/tip

## Catalogs and further information



LV 10 Low-Voltage Power Distribution and Electrical Installation Technology SENTRON • SIVACON • ALPHA

Protection, Switching, Measuring and Monitoring Devices, Switchboards and Distribution Systems

PDF (E86060-K8280-A101-A10-7600) Print (E86060-K8280-A101-A6-7600)



LV 14
Power Monitoring Made Simple
SENTRON

PDF/Print (E86060-K1814-A101-A6-7600)



LV 18
Air Circuit Breakers and Molded Case
Circuit Breakers with UL Certification
SENTRON

PDF (E86060-K8280-E347-A3-7600)



ET D1 Switches and Socket Outlets DELTA

PDF



IC 10 Industrial Controls SIRIUS

PDF/Print (E86060-K1010-A101-B1-7600)



IK PI Industrial Communication SIMATIC NET

PDF (E86060-K6710-A101-B8-7600)



**Industry Mall** 

Information and Ordering Platform on the Internet:

www.siemens.com/industrymall



CA 01 Products for Automation and Drives Interactive Catalog

Information and download:

www.siemens.com/automation/ca01



**Siemens TIA Selection Tool** 

for the selection, configuration and ordering of TIA products and devices

www.siemens.com/tst



Training for Industry SITRAIN

www.siemens.com/sitrain

The catalogs listed above and additional catalogs are available in PDF format at Siemens Industry Online Support www.siemens.com/lowvoltage/catalogs

Further information on low-voltage power distribution and electrical installation technology is available on the Internet at

www.siemens.com/lowvoltage

### Get more information

### www.siemens.com/lowvoltage

Published by For the U.S. published by Siemens AG Siemens Industry Inc.

Smart Infrastructure
Low Voltage Products

Low Voltage Products 100 Technology Drive Siemensstraße 10 Alpharetta, GA 30005 93055 Regensburg, Germany United States

PDF (Extract from E86060-K8280-A101-A10-7600) KG 1219 86 En Produced in Germany © Siemens 2019

Subject to changes and errors. The information given in this catalog only contains general descriptions and/or performance features which may not always specifically reflect those described, or which may undergo modification in the course of further development of the products. The requested performance features are binding only when they are expressly agreed upon in the concluded contract.

All product designations may be trademarks or other rights of Siemens AG, its affiliated companies or other companies whose use by third parties for their own purposes could violate the rights of the respective owner.

### Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the Internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place.

For additional information on industrial security measures that may be implemented, please visit https://www.siemens.com/industrialsecurity

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under https://www.siemens.com/industrialsecurity