



## NUMEROVALAISIN | NUMMERARMATUR | NUMBER LUMINAIRE



E = Maadoituksen jatkaminen / päätyminen  
 E = Anslutning / avslutning av jordningsledning  
 E = Continuity / termination of earth wires

Valaisimen saa asentaa vain sähköalan ammattilainen. Käytä ainostaan syöttöjännitettä ja tajuutta joka on merkitty valaisimeen/liitäntälaitteeseen. Kytki virta pois päältä ennen asennusta tai huoltoa. Tämä asennusohje on säilytettävä ja sen on oltava käytössä asennuksessa ja huollossa.

Vi rekommenderar att installationen görs av en behörig elektriker. Använd endast driftspänning och frekvens som är märkt på armaturen/förkopplingsdonet. Bryt av stömmen för installation eller service. Denna monteringsanvisning bör sparas och finns tillgänglig vid installation eller framtida service.

Only a professional electrician is allowed to do the installation. Use only rated voltage and frequency as marked in the fixture/driver. Switch off the current before installation or service. This mounting instruction must be kept available during installation and for future maintenance.

## VINO E27

NRO	E-NR	KOODI/CODE	KG	GTIN
4116420	7702434	A1VIAE	VINO IP65 MAX 20W VA	0,92
4116421	7702435	A1VIAF	VINO IP65 MAX 20W MU	0,92