

PACIFIC LED WT460/461C/X

Mounting instructions

Instructions de montage
Montageanleitung
Montage instruktio
Istruzioni di montaggio

Instrucciones de montaje
Instruções de montagem
Monteringsinstruktioner
Monteringsvejledning

Kokoonpano- ja kiinnitysohjeet
Montaj yönergesi
Szerelési utasítások
Instrukcja montażu

Návod k montáži
Návod k montáži

LEDs

~220V...240V
50 Hz/60 Hz

max
+45°C

PSD
-20°C
min

PSU
-30°C
min

30

IP66

min 30 cm
min 30 cm
min 30 cm

0682

IK08

Luminaire type	Max No of luminaires on MCB (16A type-B) *		Inrush Current Peak [A/μs]	
	PSD	PSU	PSD	PSU
WT460/461C L700	23	24	5/1000	19/275
WT460/461C/X LI300	23	23S: 24 42S: 24	5/1000	23S: 19/275 42S: 19/275
WT460/461C/X LI600	23	35S: 24 64S: 24	5/1000	35S: 19/275 64S: 19/275

* Depends on the parasitic capacity and inductance of the power mains network

Luminaire type	A [mm]	B [mm]	C [mm]	D [mm]	kg max
WT460/461C L700	450	700	721		1,9
WT460/461C/X LI300	900	1300	1321		3,25
WT460/461C/X LI600	1200	1600	1621		3,8
WT460/461C/X & TWI/TW3 LI300	900	1300	1321	1342	3,4
WT460/461C/X & TWI/TW3 LI600	1200	1600	1621	1642	4,1

WT460/461 X is ready to use with ActiLume Wireless (ACW) components.

