



# DIESEL 20000 TE XL AVR C

PORTABLE POWER

Generating Sets Range DIESEL

#### **PRODUCT ADVANTAGES**

- · Entire group guaranteed 3 years
- KOHLER air-cooled industrial engine
- Electric starter with batteries without maintenance
- · Connection interface equipped with an hour meter

AVR By regulating the voltage electronically by ±2%, depending on the model, the AVR eliminates all risk of damage to boilers or certain kinds of electronic equipment.

### Range DIESEL

Both long run times and very long life for professional applications.

















# DIESEL 20000 TE XL AVR C

# **GENERAL SPECIFICATIONS**

Range	DIESEL
Frequency (Hz)	50
Max power LTP (kW) *	15.20
Max power LTP (kVA)	19
Nominal voltage (V)	400
Number of Phase	Three phase
Fuel	Fuel
Tank (L)	35
75% cons. (I/h) *	3.80
75% Autonomy (h) *	9.20
Sound power level guaranteed LwA dB(A)	110
Acoustic pressure level @1m in dB(A)	95
Acoustic pressure level @7m in dB(A)	81

#### **ENGINE SPECIFICATIONS**

Engine model	KOHLER DIESEL
Engine ref.	KD625-2
Distribution	Diesel O.H.V.
Start	Electrical
Oil Guard	Oui
Capacity (cm3)	1248
Oil capacity (L)	2.60

#### ALTERNATOR SPECIFICATIONS

Technology	Without collar or brush
AVR Regulation	Yes
Indication of protection	IP 23
Insulation class	Н

#### PLUGS AND PANEL DESCRIPTIVE

1 230V 10/16A socket - circuit breaker + 1 400V 32A socket - circuit breaker + emergency stop button + hour meter + indicator + MICS **MODYS** 

# **DIMENSIONS AND WEIGHT**

Lenght (cm)	118.40
Width (cm)	66
Height (cm)	93
Dry Weight (kgs)	311

#### **PACKAGING**

Packaging type	Box	
Length (cm)	120.40	
Width (cm)	68	
Height (cm)	95	
Weight (kg)	314	
Pallet type		
Number of box by pallet	0	
Pallet height (cm)	0	
weight of the packaged Pallet (kg)	0	





# DIESEL 20000 TE XL AVR C

# **ACCESSORIES SUPPLIED**



User and maintenance manual

## **OPTIONS**

	R03B	Diferential protection	This set includes a differential switch, a hour meter, the plugs and a thermal circuit breaker.
	RSTART	Wireless remote	Remote control in order to start or stop the generating set until a distance of 50 meters (needs the installation of a MODYS control panel)
Fibre Control of the	VERSO5	Automatic start panel	Switches over automatically if the mains fails, 40A or 100A 1P or if the mains fails, 25A or 40A 3P (needs the installation of a MODYS control panel). Includes the battery charger.
	RPM	Set of male plugs	Male plugs for all models made up of : 2 x 16 A/230 V, EEC17: 1 x 16A/230 V, 1 x 32A/230 V and 1 x 16A/400V
	RPQ	Earth spike	For earthing your generator set. Galvanised 1 m long spike, supplied with 2 m of 10 mm² cable.

