




Instructions for Use


Model 1490-1

The **Smokin' Gun™** Aerosol Adapter is designed for use with **25S Smoke Check™** Smoke Detector Tester. It is recommended that this adapter be used for all open delivery testing. The **Smokin' Gun™** directionalizes the test aerosol to the detector's sensing chamber while evaporating the propellant which causes residue. The **Smokin' Gun™** is quick, easy, accurate and reusable, designed to be used both by hand and with the **Versa-Tools™** line of professional equipment.



To Use:

1. Remove cap from 25S Smoke Check✓™, set aside.
2. **Optional** – If the can has no rim, place the non-rim adapter on the bottom of the aerosol adapter.
3. Snap the aerosol adapter on to can, fit over actuator. Arrow on top of actuator must point toward the extension tube.
4. Point the tube at the detector and release a burst of the aerosol by depressing actuator for 1 to 3 seconds. In areas with high air movement, place the end of the telescoping tube against the detector and release aerosol. The superior design of the telescoping tube gathers the moisture from the propellant, while the 18" length allows adequate space for all propellant to evaporate, resulting in absolutely no residue. The detector should alarm when tested in accordance with these instructions.



107 Garlich Drive
 Elk Grove Village, Illinois 60007
 P: 847-427-8340 F: 847-427-8343
 WWW.HOMESAFEGUARD.COM
 expert@homesafeguard.com