



FRONT VIEW / VISTA FRONTAL



- ① LCD Display / *Pantalla LCD*
- ② Power LED / *LED de Encendido*
- ③ Control keys / *Tecclas de Control*
- ④ Lock LED / *LED de señal enganchada*

- ⑤ Alarm LED / *LED de alarma*
- ⑥ Lock key / *Tcla de bloqueo*
- ⑦ Menu key / *Tcla de men*
- ⑧ Enter key / *Tcla de entrada*

TOP VIEW / VISTA SUPERIOR



- ⑨ RF IN
- ⑩ RF OUT
- ⑪ USB

MENU TREE / ÁRBOL DE MENÚS

