



# High-Bay PIR Spot Detector (319)

freedom in lighting

The 319 High-Bay PIR Spot Detector is a compact unit containing sensors to provide energy-saving functions when used in a DALI system.

Functioning as a presence detector, the unit can turn the lights on when a room is occupied, and off when unoccupied. It is fully compatible with Helvar's lighting system design and control software: Designer, and Toolbox.

# **Features and Connections**



#### **PIR Sensor**

Detects movement within the detection range, allowing load control in response to changes in room occupancy.

#### **Status LED**

The red LED flashes to indicate:

- Valid setting received (single flash of LED)
- Identify active (LED flashes repeatedly)

### **DALI Connection**

The DALI connection is made via DA+ and DA- terminals. The device is not polarity-sensitive.

## Sensitivity, Time-Outs, Identify

#### **Sensitivity**

Adjust the sensitivity using Designer or Toolbox – Helvar's lighting system design and control software. The factory default setting is 9 (maximum).

**Note:** On maximum sensitivity, the detector unit is **extremely sensitive** to movement and may detect through glass, thin walls or partitions. If this causes a problem, reduce its sensitivity.

The temperature difference between the detection target and the background must be at least 4 °C.

### Adjusting On, Exit and Transition Time-Outs

The default time-outs for On, Exit and Transition can be altered using Designer or Toolbox.


## **Identify: Check Connection to DALI Network**


To make sure that the sensor is correctly connected to the DALI network, use the *Identify* function in Designer or Toolbox. The sensor's status LED flashes repeatedly until *Identify* is cancelled.

# **Detection Pattern**



freedom in lighting






# **Installation**

The High-Bay PIR Spot Detector can be mounted into a ceiling or wall void or onto a back box. The following steps are required for all installations of the unit.

- 1. Connect the DALI connector to the socket located at the rear of the sensor.
- 2. Flush fixing: Insert the unit into the ceiling or wall (see 'Connection and Fixing: Flush Fixing' on page 3); or Surface mounting: Install the unit using the SBB-A or the SBB-P surface back boxes, as appropriate (see 'Connection and Fixing: Surface Mounting' on page 4).
- 3. Power the unit up.
- 4. Configure the unit using Designer or Toolbox.
- 5. If the load triggered by the sensor comes on, by default it will take 20 minutes (of no movement detected) for the load to switch off.






### **Installation Notes**

freedom in lighting

- Do not fix the sensor to an unstable or vibrating surface.
- Do not install the sensor within 1 m of any lighting, forced air heating, or ventilation equipment.

## Connection and Fixing: Flush Fixing






## **Connection and Fixing: Surface Mounting**

freedom in lighting

There are two different mounting procedures: one onto the SBB-A surface back box, the other onto the SBB-P surface back box using the supplied silicone gasket must always be used.

Both back boxes must be ordered separately.

### Mounting onto Surface Back Box SBB-A (IP 40)






# Mounting onto Surface Back Box SBB-P (IP 40)

freedom in lighting












3.




4.




**5**.




6.



**7**.



8.



## **Technical Data**



freedom in lighting

#### **Connections**

External power / DALI: Removable connector block.

Wire size: 0.5 mm<sup>2</sup> – 1.5 mm<sup>2</sup>

solid or stranded.

Cable rating: All cables must be mains

rated

Max. length: 300 m @ 1.5 mm<sup>2</sup>

**Power** 

**DALI supply input:** 13 V to 22.5 V

**DALI consumption:** 15 mA

Sensors

Presence detector: PIR: Passive infrared

presence detector

**Infrared receiver:** For remote control

commands.

Note: Adjust sensitivity using Designer or Toolbox (not by remote control unit).

Mechanical data

Mounting hole

68 mm

diameter:

Bezel diameter: 76 mm

Material (casing): Flame-retardant ABS
Finish / Colour: Matt / White RAL 9003

**Weight:** 82 g **IP code:** IP40

Operating conditions

Ambient temperature: 0 °C to +35 °C

Relative humidity: Max. 90 %, noncondensing

Storage temperature:  $-10 \, ^{\circ}\text{C}$  to  $+70 \, ^{\circ}\text{C}$ 

**Conformity and standards** 


 EMC emission:
 EN 61000-6-1

 EMC immunity:
 EN 61000-6-3


 Safety:
 EN 60730-1

**Environment:** Complies with WEEE and

RoHS directives.



Dimensions (mm)



Helvar Ltd Hawley Mill Hawley Road Dartford Kent DA2 7SY United Kingdom www.helvar.com